


**KW2G/KW2G-H  
Eco-POWER METER  
User's Manual**

---


**Basic setting to measure by KW2G Eco-POWER METER**

When wiring the main unit and the current transformer (CT) and setting the basic setting after power on, you can measure the power  
 The basic setting of MODE1 is necessary to measure.  
 In order to use the other functions, the settings of the each parameter are necessary.



**Basic setting to measure by KW2G-H Eco-POWER METER**

When wiring the main unit and the current transformer (CT) and setting the basic setting after power on, you can measure the power  
 The basic setting of MODE1 is necessary to measure.  
 In order to use the other functions, the settings of the each parameter are necessary.



## Cautions for Your Safety

Read the manual carefully before installing, running and maintenance for proper operation. Before using, master the knowledge of the equipment, safety information and all of other notes.

This manual uses two safety flags to indicate different levels of danger.



### WARNING

A handling error could cause serious physical injury to an operator and in the worst case could even be fatal.

- Always take precautions to ensure the overall safety of your system, so that the whole system remains safe in the event of failure of this product or other external factor.
- Do not use this product in areas with inflammable gas. It could lead to an explosion.
- Exposing this product to excessive heat or open flames could cause damage to the lithium battery or other electronic parts.



### CAUTION

A handling error could cause serious physical injury to an operator or damage to the equipment.

- To prevent abnormal exothermic heat or smoke generation, use this product at the values less than the maximum of the characteristics and performance that are assured in these specifications.
- Do not dismantle or remodel the product. It could lead to abnormal exothermic heat or smoke generation.
- Do not touch the terminal while turning on electricity. It could lead to an electric shock.
- Use the external devices to function the emergency stop and interlock circuit.
- Connect the wires or connectors securely. The loose connection might cause abnormal exothermic heat or smoke generation.
- Do not allow foreign matters such as liquid, flammable materials, metals to go into the inside of the product. It might cause exothermic heat or smoke generation.
- Do not undertake construction (such as connection and disconnection) while the power supply is on.
- Do not use at secondary side circuit of inverter. It might cause exothermic heat or damage.

## Copyright and trademark

- Panasonic Industrial Devices SUNX Co., Ltd. owns the copyright of this manual.
- We stiffly refuse the reproduction of without permission from this manual.
- Modbus Protocol is a communication protocol that the Modicon Inc. developed for PLC.
- Other company names and the product names are the trademarks or registered trademarks of each company.

## **Introduction**

Thank you very much indeed for purchasing  
'KW2G Eco-POWER METER'.

In this manual, we explain the usage of  
'KW2G Eco-POWER METER' in detail.

Please use it correctly after understanding the content  
enough.

# Table of Contents

---

Chapter 1 Unit's Outline .....	1
1.1 Unit's Name and Model Numbers .....	1
1.2 Combination devices.....	1
1.3 Firmware .....	1
1.4 Option .....	2
1.5 Other tools .....	3
1.6 Measurement items .....	4
Chapter 2 Parts Name and Working .....	5
2.1 Parts Name .....	5
2.2 Key's Functions.....	7
Chapter 3 Installation .....	8
3.1 Measured-circuit .....	8
3.2 Connection between the main unit and the expansion unit.....	8
3.3 DIN rail mounting .....	9
3.4 Terminal arrangement .....	10
3.4.1 Main unit (common to AKW2010G and AKW2020G) .....	10
3.5 Wiring Diagram .....	11
3.5.1 In case of using only main unit .....	11
3.5.2 In case of using main unit and connected expansion units.....	13
3.5.3 In case of using simple measuring mode.....	16
3.6 How to attach the Current Transformer (CT).....	17
3.7 For input connection .....	18
3.8 For Output connection .....	20
3.9 RS485 communication.....	20
3.10 Backup battery (only for KW2G-H SD card type) .....	22
3.11 Low Voltage Directive .....	23
Chapter 4 Settings.....	24
4.1 Setting for KW2G main unit and Expansion unit (power measurement) .....	24
4.2 Setting for KW2G-H main unit SD card type and Expansion unit (power measurement) .....	28
4.3 Setting Mode Explanation for Main unit and Expansion unit (power measurement).....	33
4.3.1 Mode 1.....	33
4.3.2 Mode 2.....	41
4.3.3 Mode 3.....	42
4.3.4 Mode 4.....	44
4.3.5 Mode 5.....	46
4.3.6 Remove SD memory card *Only KW2G-H.....	47
Chapter 5 Various Functions.....	48
5.1 LOCK mode .....	48
5.2 Pulse output function .....	48
5.2.1 Output depends on integrated electric power .....	48
5.2.2 Instantaneous electric power alarm .....	48
5.2.3 Current alarm.....	48
5.2.4 Stand-by power alarm .....	48
5.2.5 Output depends on count value .....	48
5.2.6 General purpose output.....	49
5.2.7 Error alarm.....	49
5.3 Counter function.....	49
5.4 General-purpose output function .....	50
5.5 Hour meter function .....	51
5.6 Log data writing function.....	52
5.6.1 In case that SD memory card is always inserted to card slot .....	52
5.6.2 In case that you insert SD memory card .....	53
5.6.3 Unit memory .....	55
5.6.4 Format for written file.....	56
5.6.5 File name and Saved folder .....	59
5.6.6 Logging data.....	61

Chapter 6 Display of each Value.....	62
6.1 Working of Monitor Display.....	62
6.1.1 KW2G Main unit, Expansion unit (Power measurement).....	62
6.1.2 KW2G-H Main unit SD card type, Expansion unit (Power measurement).....	67
6.2 Display of each measurement value.....	72
6.3 Display for power monitoring mode.....	72
6.3.1 Integrated electric power.....	72
6.3.2 Instantaneous electric power.....	73
6.3.3 Current.....	74
6.3.4 Voltage.....	75
6.3.5 Electricity Charge.....	76
6.3.6 Carbon dioxide conversion value.....	76
6.3.7 Power factor.....	77
6.3.8 Frequency.....	77
6.3.9 Hour meter.....	78
6.3.10 Counter / Pulse input status.....	80
6.4 Display for option mode *only KW2G-H SD card type.....	81
6.4.1 Calendar/Timer.....	81
6.4.2 Daily integrated electric power (kWh).....	82
6.4.3 Hourly integrated electric power (kWh).....	83
6.5 Other indication.....	85
6.5.1 Indication while communication.....	85
6.5.2 Error indication.....	85
Chapter 7 Communication.....	86
7.1 Communication Procedures.....	86
7.2 Communication timing.....	86
7.3 MEWTOCOL Communication.....	87
7.3.1 Overview of MEWTOCOL-COM (RS485, USB).....	87
7.3.2 Data Register List (MEWTOCOL).....	88
7.3.3 Error Codes.....	94
7.3.4 Command.....	94
7.4 MODBUS (RTU) Communication.....	96
7.4.1 Overview of MODBUS (RTU).....	96
7.4.2 Data Register List (MODBUS communication).....	99
7.5 Status.....	108
Chapter 8 How to update the firmware.....	109
8.1 Prepare Eco-POWER METER to update.....	109
8.2 Update the firmware using KW Version Upgrade Tool.....	109
Chapter 9 Specifications.....	114
9.1 Main unit, Expansion unit (power measurement).....	114
9.2 Measurement.....	115
9.3 Output Specifications.....	116
9.4 Communication Specifications.....	117
9.5 Main Unit Memory Specifications (only KW2G-H SD card type: AKW2020G).....	118
9.6 External Memory Specifications (only KW2G-H SD card type: AKW2020G).....	119
9.7 Self-diagnostic function.....	120
9.8 Power Failure Memory.....	120
9.9 Applicable standard.....	120
9.10 Dedicated Current Transformer Specifications.....	121
Chapter 10 Mounting.....	122
10.1 Dimensions.....	122
10.1.1 KW2G Main unit.....	122
10.1.2 KW2G-H SD card type Main unit.....	123
10.1.3 Expansion unit (power measurement).....	124
10.1.4 Dedicated CT.....	125

## Cautions before using

---

### ■ Installation environment

#### ◇ Do not use the Unit in the following environments.

- Where the unit will be exposed to direct sunlight and where the ambient temperature is outside the range of -10 to 50 °C.
- Where the ambient humidity is outside the range of 30 to 85 % RH (at 20°C, non-condensing) and where condensation might occur by sudden temperature changes
- Where inflammable or corrosive gas might be produced
- Where the unit will be exposed to excessive airborne dust or metal particles
- Where the unit will be exposed to water, oil or chemicals
- Where organic solvents such as benzene, paint thinner, alcohol, or strong alkaline solutions such as ammonia or caustic soda might adhere to the product
- Where direct vibration or shock might be transmitted to the product, and where water might wet the product
- Where the place near high-voltage cable, high-voltage device, power line, power device.
- Where the place near a machinery with transmission function such as amateur radio.
- Where the place near a machinery which occurs the big switching surge

#### ◇ Please use the Unit according to the specifications described in this manual. Otherwise, it may malfunction or cause fire and an electric shock.

- Connect to the power supply in compliance with the rating.
- Refer to the wiring diagram to ensure proper wiring for the power supply, input and output.
- Do not perform wiring or installation with a live line. It may also lead to circuit burnout or fire by way of the secondary CT side opening.

### ■ Installation

- Eco-POWER METER is designed to be used in a control panel.
- The power supply terminal and voltage input terminal of the main unit is common. Therefore if additional noise affects the power supply line, incorrect measurements may result.
- Installation and wiring must be performed by expert personnel for electrical work or electric piping.
- Do not add an excess power to the display. It might break the inner liquid crystal.

### ■ As to measurement

- If there is some distortion by harmonic or waveform, it may not measure correctly. Please check with the actual system before adopting it.
- It might not measure an instantaneous current such as an inrush current or an welding machine.
- When measuring the below loads, it might not satisfy with the accuracy guarantee.
  - Out of rating current, Load with low power factor,
  - Load with winding current, Load with ferromagnetic field
- Power factor operation is a method assuming balanced load. The error might be big when it measures unbalanced load.
- **It takes time to update monitor display when many units are connected. However, data update cycle is not changed.**
- **The unevenness will be large when using outside of rated frequency. In this case, set the shift average frequency big.**

### ■ Static electricity

- Discharge static electricity touching the grounded metal etc. when you touch the unit.
- Excessive static electricity might be generated especially in a dry place.

### ■ Cleaning

- Wipe dirt of the main unit with soft cloth etc. When thinner is used, the unit might deform or be discolored.

## ■ Power supply

- Connect a breaker to the voltage input part for safety reasons and to protect the device.  
The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- Do not turn on the power supply or input until all wiring is completed.

## ■ Before power on

Please note the following points when turning on power at the first time.

- Confirm there are neither wiring rubbish nor especially an electrical conduction when installed.
- Confirm neither the power supply wiring, the I/O wiring nor the power-supply voltage are wrong.
- Tighten the installation screw and the terminal screw surely.
- Use an electric wire applicable to the rated current.

## Chapter 1 Unit's Outline

KW2G Eco-POWER METER is the wattmeter that can measure electric power, current, voltage, PF and so on with combination of one main unit and expansion units (power measurement, power measurement + pulse output).

By connecting main unit and expansion unit (power measurement, power measurement + pulse output), it can measure up to 8-circuit (16-circuit of single-phase two-wire system).

By connecting expansion unit of pulse input type, it can measure pulse signal from a sensor.

By connecting expansion unit of analog input type, it can measure digital conversion value (voltage/current) from a sensor.

### 1.1 Unit's Name and Model Numbers

#### ●Main unit

Product name	Model No.	Log function	Connecting method	
KW2G Eco-POWER METER Main unit	AKW2010G	Not available	• Power supply terminal (Voltage input terminal)	M3.5+screw
			• Pulse I/O terminal	M3+screw
KW2G-H Eco-POWER METER Main unit SD card type	AKW2020G	Available	• RS485 communication terminal	M3+screw
			• Current transformer(CT)	Connector
			• USB communication	Connector

#### ●Expansion unit

Product name	Model No.	Connecting method	
Expansion unit (Power measurement)	AKW2110G	Current transformer (CT)	Connector *Connect to main unit with the connector.

Note)

It is impossible to measure by only the expansion unit.

Be sure to connect expansion units to the main unit.

### 1.2 Combination devices

Product name	Model No.	Connecting method	
Expansion unit (Power measurement + Pulse output)	AKW2160G	Current transformer (CT)	Connector
		Pulse output terminal *Connect to main unit with the connector.	M3+ screw
Expansion unit (Pulse input)	AKW2152G	Pulse input terminal *Connect to main unit with the connector.	M3+ screw
Expansion unit (Analog input)	AKW2182G	Analog input terminal *Connect to main unit with the connector.	M3+ screw

**\*In this manual, we explain the usage of 'KW2G Main unit', 'KW2G-H Main unit' and 'Expansion unit (Power measurement)'.**

### 1.3 Firmware

#### ●Combination software using the expansion unit

Expansion unit	firmware	Firmware of AKW2010G	Firmware of AKW2020G
AKW2110G	Ver.1.00 or later	Ver.1.00 or later	Ver.1.00 or later
AKW2152G	Ver.1.10 or later	Ver.1.02 or later	Ver.1.00 or later
AKW2182G	Ver.1.10 or later	Ver.1.02 or later	Ver.1.00 or later
AKW2160G	Ver.1.20 or later	Ver.1.04 or later	Ver.1.01 or later

● For using the additional functions

	Functions		
Model number	-Check the pulse input condition with the main unit or communication -Set pulse output width	-Display an integrated electric power with unit of 0.001kWh -General-purpose output function	-Eject SD memory card -Error alarm output
AKW2010G	Ver.1.04 or more	Ver.1.05 or more	Ver.1.06 or more
AKW2020G	Ver.1.01 or more	Ver.1.02 or more	Ver.1.03 or more
AKW2110G	—	Ver.1.04 or more	Ver.1.05 or more
AKW2160G	Ver.1.00 or more	Ver.1.01 or more	Ver.1.02 or more
AKW2152G	Ver.1.01 or more	—	—
AKW2182G	—	—	—

	Functions
Model number	-Hour meter
AKW2010G	Ver.1.10 or more
AKW2020G	Ver.1.10 or more
AKW2110G	Ver.1.05 or more
AKW2160G	Ver.1.02 or more
AKW2152G	Ver.1.01 or more
AKW2182G	—

## 1.4 Option

● Dedicated current transformer clamp-on type (CT)

Product name	Rated primary current	Model No
Dedicated current transformer for 5A/50A	5A / 50A	AKW4801C
Dedicated current transformer for 100A	100A	AKW4802C
Dedicated current transformer for 250A	250A	AKW4803C
Dedicated current transformer for 400A	400A	AKW4804C
Dedicated current transformer for 600A	600A	AKW4808C

● Dedicated current transformer through type (CT)

Product name	Rated primary current	Model No
Dedicated current transformer for 50A/100A	50A / 100A	AKW4506C
Dedicated current transformer for 250A/400A	250A / 400A	AKW4507C
Dedicated current transformer for 600A	600A	AKW4508C

## ●Others

Product name	Model No
Mounting rail	AT8-DLA1
Fastening plate	ATA4806
Battery (included with AKW2020G)	AFPG804 *1
Extension cable for CT 3m	AKW4703
Extension cable for CT 5m	AKW4705

\*1 only for KW2G-H SD card type

**1.5 Other tools**

Product name	Functions	Model No
Data collection software KW Monitor	•Monitoring and logging the measured values.	Download from our website. Free of charge
Power display tool KW View	•It makes graph by using data from Eco-POWER METER	Download from our website. Free of charge
Eco-POWER METER Version Upgrade Tool KW Version Upgrade Tool	•You can upgrade the firmware of main unit and expansion unit. •USB driver is included.	Download from our website. Free of charge

Note) Members registration is required to download.

## 1.6 Measurement items

Item		Unit	Data range
Integrated electric power (Active) *1		kWh/ MWh	·6-digit display 0.00 to 9999.99MWh (minimum unit: 0.01kWh) ·9-digit display 0.00 to 9999999.99kWh (minimum unit: 0.01kWh) 0.000 to 999999.999kWh (minimum unit: 0.001kWh)
Instantaneous electric power	Active *2	kW	-9999.99 to 0.000 to 9999.99
	Reactive *3	kvar	-9999.99 to 0.00 to 9999.99
	Apparent	kVA	0.00 to 9999.99
Current	R-current	A	0.000 to 6000.00
	N/S-current	A	0.000 to 6000.00 (calculated value)
	T-current	A	0.000 to 6000.00
Voltage	R(RS)-voltage	V	0.0 to 9999.9
	S(RT)-voltage	V	0.0 to 9999.9 (calculated value)
	T(TS)-voltage	V	0.0 to 9999.9
Electricity charge *4			0.00 to 999999
Conversion value	Carbon dioxide	kg-CO <sub>2</sub>	0.00 to 999999
Power Factor *2			-1.00 to 0.00 to 1.00 (without identify leading phase and lagging phase)
Frequency *5		Hz	47.5 to 63.0
Hour meter *6	OFF-time	Hour	0 to 99999.9
	ON-time 1		
	ON-time 2		
	Maintenance time		
	Actual work time		
	Ratio of ON-time 1	%	0.0 to 100.0
Ratio of ON-time 2			
Pulse counter *5 *7			0 to 999999

\*1 KW2G can measure regeneration electric power.

Integrated electrical power is not integrated (not subtracted) when detecting regeneration power.

\*2 While detecting regeneration electric power, minus is displayed on instantaneous active power and power factor.

\*3 It determines pulse or minus of instantaneous reactive power by the input measuring voltage and the input measuring current.

When harmonics or a wave pattern is warped, it may not determine correctly.

\*4 Eco-POWER METER is designed chiefly to manage saving energy.

It is neither intended nor can it be legally used for billing.

\*5 Frequency and pulse counter are only for main unit.

\*6 Expansion unit (Analog input) doesn't have the hour meter function.

With expansion unit (Pulse input), maintenance time and actual work time can be measured.

Maintenance time by using pulse input can't be measured with expansion unit (Power measurement) and expansion unit (Power measurement + Pulse output).

For ratio of ON-time1 and ratio of ON-time2, it uses measuring value inside every 1 sec., therefore it may be different when you compare with OFF-time, ON-time1, ON-time2, maintenance time and actual work time.



Hour meter function can be used only with main unit and one expansion unit.

\*7 Displayed digit of pulse counter differs according to the pre-scale set by pre-scale setting mode.

## Chapter 2 Parts Name and Working

### 2.1 Parts Name


Front view



Side view


<Main unit>

<Expansion unit>




<Display>

- ① LOCK indicator  
Key operation is invalid while lighting.
- ② TX/RX indicator  
Lighting when communication
- ③ OUT indicator  
Lighting when pulse output
- ④ Unit number indicator  
M: Main unit  
1 to 7: Expansion unit
- ⑤ Setting mode indicator
- ⑥ Each measurement value



<Display (SD card type)>

- ① LOCK indicator  
Key operation is invalid while lighting.
- ② TX/RX indicator  
Lighting when communication
- ③ OUT indicator  
Lighting when pulse output
- ④ Unit number indicator  
M: Main unit  
1 to 7: Expansion unit
- ⑤ Setting mode indication
- ⑥ Each value indicator
- ⑦ LOG indicator  
Lighting while logging
- ⑧ SD indicator  
Lighting while inserting SD memory card



## 2.2 Key's Functions

<MODE>	• Shift unit number to display
<MODE> (continuous press 3-sec)	• Use to shift setting mode
<SET>	• Use to set each value entered • Reset stand-by alarm while output the alarm (only available while output the stand-by alarm)
<SET> (continuous press 3-sec)	• All keys locked • Release lock mode while in lock mode
<ITEM/Δ>	• To select measured value display (While monitoring) • To select setting value (While setting mode)
<SET> and <ITEM/Δ>	• To select measured value display (While monitoring) • To select setting value (While setting mode)
<ITEM/Δ> (continuous press 3-sec)	• Shift measured items to display (Instantaneous electric power, current, voltage)
<SET> and <MODE> (continuous press 3-sec)	• To reset the measured value

## **Chapter 3 Installation**

### **3.1 Measured-circuit**

- It is not impossible to use to measure several loads by different strain power supply.
- Each unit (main unit, expansion unit (power measurement, power measurement + pulse output)) can measure 2-circuit of single-phase two-wire system, and 1-circuit of single-phase three-wire system or three-phase three-wire system. Each unit can be used with different phase and wire system. However be sure to check the wiring carefully.
- It is impossible to measure by only the expansion unit. Connect expansion units to main unit. Up to 7 expansion units are connected to 1 main unit. You can use with the combination of power measurement, power measurement + pulse output, pulse input and analog input as expansion units.


#### \*Power source system

- Power source system is the electrical power system from one power source (normally one transformer).
- KW2G can measure 1-system max. 16-circuits of 1P2W system and 1-system max. 8-circuit of 1P3W and 3P3W system by connecting a main unit and expansion units (power measurement, power measurement + pulse output).
- In order to measure several systems, it is necessary to use one main unit for each system.

### **3.2 Connection between the main unit and the expansion unit**

- Turn off the power of main unit when connecting expansion units.
- Peel off connector label on the side before connecting.  
(Do not peel off connector labels when not connecting.)
- It expands by connecting each male connector to female connector. Female connector is on the other side of male connector.
- After connecting, push the hooks into the unit to fix the expansion unit.
- Up to 7 expansion units can be connected per one main unit.

Note) Communication will be stopped or the measurement data will be lost when the units are removed or connected while turn on power.




### 3.3 DIN rail mounting

Connect all expansion units to the main unit before mounting DIN rail, then mount all connected units to DIN rail.

#### Mount


- 1) Hang the unit on DIN rail.
- 2) Push it till making click sound and mount.



Note) Check the position of DIN hook (Fig.1) before mounting.


When several expansion units are connected and mounted to DIN rail, moving the hooks lower (Fig.2) makes mounting easy. After mounting, return to the position of Fig.1.

<Back of main unit> <Back of expansion unit>



#### Remove

- 1) Insert minus driver etc. to DIN hook and displace down below.
- 2) Lift it in the direction of the arrow and remove it.




### 3.4 Terminal arrangement

Be sure to wire correctly according to the terminal arrangement and wiring diagrams. After completing wiring, be sure to attach the terminal cover for safety reasons.

#### 3.4.1 Main unit (common to AKW2010G and AKW2020G)

No.	Function		Screw
Top	①	P1	M3.5
	②	P0	
	③	P2	
	④	NC	
Mid	⑤	+	M3
	⑥	-	
	⑦	+	Pulse input
	⑧	-	
Bottom	⑨	+	RS485
	⑩	-	
	⑪	E	





**⚠ The input voltage to each terminal is as follows.**

Terminal	Phase and wire	Terminal	Input voltage
Measured voltage input	Single-phase, two-wire	①-② (P1-P0)	100-240VAC (100-240V~) (Line voltage)
	Single-phase, three-wire	①-②-③ (P1-P0-P2)	100-120VAC (100-120V~ :3W) (Phase voltage)
	Three-phase, three-wire	①-②-③ (P1-P0-P2)	100-240VAC (100-240V 3~) (Line voltage)



#### Caution for Wiring

- Terminal fastening torque should be 0.5 to 0.6N·m for M3 screw and should be 0.8 to 1.0N·m for M3.5 screw. In case of using a crimping terminal, use it with insulating sleeve applicable to M3 screw or M3.5 screw.
- To protect the device, it is necessary to install power switch and circuit breaker in the power supply circuit. And this has no built-in power switch, circuit breaker or fuse for measured voltage input parts. Therefore it is necessary to install them in the circuit near this unit.
- We recommend a wire with the cross section of 0.75 to 1.25mm<sup>2</sup> for power supply line and measured voltage input line.
- Use with 10m or less of the input line and 100m or less of the output line.
- Use flame-resistant cable for each wiring.

<M3.5 screw> width: 6.6mm or less



<M3 screw> width: 5.8mm or less



### 3.5 Wiring Diagram

#### 3.5.1 In case of using only main unit


Please connect a breaker (3 to 15A) to the power supply (voltage input) part for safety reasons and to protect the device.

#### Single-phase two-wire system

◆When measuring a load with rated input voltage

One CT is needed to measure one load.

The below shows that it measures 2-circuit using 2 CTs connected to connectors of unit.



Note)


- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) 2 CTs should be same.

◆When measuring a load with exceed input voltage.

Voltage transformer (VT) is needed when you measure a load with over rated input voltage.


Use VT, its secondary side rating is 110V.

Grounding the secondary side of VT and CT is not necessary with low-voltage circuit.



**Single-phase three-wire system/Three-phase three-wire system**

- ◆When measuring a load with rated input voltage  
Two CTs are needed to measure one load.




Note)

- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) 2 CTs should be same.

- ◆When measuring a load with exceed input voltage.

Voltage transformer (VT) is needed when you measure a load with over rated input voltage.  
Use VT, its secondary side rating is 110V.  
Grounding the secondary side of VT and CT is not necessary with low-voltage circuit.




### 3.5.2 In case of using main unit and connected expansion units

Please connect a breaker (3 to 15A) to the power supply (voltage input) part for safety reasons and to protect the device.

#### Single-phase two-wire system

◆When measuring a load with rated input voltage



Note)

- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) Using all CTs for one unit should be same.

◆When measuring a load with exceed input voltage.

Voltage transformer (VT) is needed when you measure a load with over rated input voltage.


Use VT, its secondary side rating is 110V.

Even if the secondary side voltages of VT are same, when the power source system is different, one main unit is necessary for each power source system.

(Refer to the previous 3.6.1 in detail.)

Single-phase three-wire system/Three-phase three-wire system

◆When measuring a load with rated input voltage



Note)

- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) Using all CTs for one unit should be same.

◆When measuring a load with exceed input voltage.

Voltage transformer (VT) is needed when you measure a load with over rated input voltage.

Use VT, its secondary side rating is 110V.


Even if the secondary side voltages of VT are same, when the power source system is different, one main unit is necessary for each power source system.

(Refer to the previous 3.6.1 in detail.)

Single-phase three-wire system and Single-phase two-wire system

Three-phase three-wire system and Single-phase two-wire system

◆When measuring a load with rated input voltage



Note)

- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) In order to measure a load with single-phase 2 wire system 100V, wire CT1 to R and CT2 to T.
- (3) Using all CTs for one unit should be same.

◆When measuring a load with exceed input voltage.

Voltage transformer (VT) is needed when you measure a load with over rated input voltage.

Use VT, its secondary side rating is 110V.

Even if the secondary side voltages of VT are same, when the power source system is different, one main unit is necessary for each power source system.

(Refer to the previous 3.6.1 in detail.)

3.5.3 In case of using simple measuring mode

It can measure electric power using only measured current with fixing voltage and power factor. You can use this function when it is impossible to input measured voltage due to the load situation or wiring conditions.

Simple measuring is a function to grasp rough electric power of the measurement circuit without measuring voltage.


Please connect a breaker (3 to 15A) to the power supply (voltage input) part for safety reasons and to protect the device.

[Caution]


During simple measuring, it doesn't guarantee the accuracy because voltage and power factor are fixed. Frequency of the operating power supply is displayed.

Wiring example:

Single-phase two-wire



Single-phase three-wire/Three-phase three-wire



Note)

- (1) When wiring CT, wire correctly according to this, K for power supply side and L for load side.
- (2) Using all CTs for one unit should be same.

### 3.6 How to attach the Current Transformer (CT)

- One CT is needed for 1 unit when measuring 1P2W (2 CTs for 2-circuit). Two CTs are needed when measuring 1P3W/3P3W. Using all CTs for one unit should be the same.
- Check beforehand that the thickness of the electric wire is smaller than the through-hole of the CT.
- When connecting CT, connect the secondary side to the terminal of the main unit first, and after that wire the primary side to a load electric wire. Incorrect order might cause an electric shock or break CT.
- The CT has polarity. Wire correctly according to the K and L marks. **Wrong direction can't measure correctly.**
- When closing CT, check that there is no foreign materials on the divided face. And make sure it is closed securely once the wire is in place; **if not the measurement value will be not accurate.**
- When CT's cable is extended, it is possible to extend up to about 10m with the cable of AWG#22 or more cross section under the environment without noise at all. Please use the thick cable as much as possible.
- Separate the wiring (strong electric part) of the measured voltage input terminal (operating power supply terminal) from the CT cable. It may not satisfy the accuracy due to noise.


#### ◆ To connect CT with secondary side current 5A

##### How to set for measuring by combination with CT (secondary side current 5A)


- (1) Select 5A at CT type setting mode (CT-T).
- (2) Set the primary current of measured CT (secondary side current 5A) at primary side current of CT setting mode (CT-1).  
<ex> If the measured CT is 400A/5A, set to '400'.
- (3) Clamp the dedicated CT for 5A (AKW4801C), which is connected to the main unit first, to secondary side of the CT (secondary side current 5A). CT direction (K→L) should be set for the commercial CT direction.

**\*Set the CT (secondary side current 5A) and the dedicated CT for 5A approximately 1m apart. If the two CTs are set too close each other, it may not measure accurately due to magnetic field interference.**

(Connection example)  
With Ammeter etc.



Without Ammeter



3.7 For input connection

● Pulse input (Main unit)

• Contact input

Use highly reliable metal plated contacts. Since the contact's bounce time leads directly to error in the count value, use contacts with as short a bounce time as possible. In general, select 30Hz for max. counting speed.

• Non-contact input (Transistor input)

Connect with an open collector. Use the transistor with the following specifications.  $V_{CE0}=20V$  min.

$I_C=20mA$  min.  $I_{CBO}=6 \mu A$  max

Use transistors with a residual voltage of less than 2V when the transistor is ON.


\*Short-circuit impedance should be less than  $1k\Omega$ .

(When the impedance is  $0\Omega$ , drain current is approx. 7mA.)

Open-circuit impedance should be more than  $100k\Omega$ .



• Input wiring

Please wire up to 10m by using a shielded wire or a metallic electric wire tube individually.



(Note)


Operating power supply input part and measured voltage input are not insulated to pulse input parts. So the input equipment must have the power supply transformer in which the secondary side is not grounded with the primary and secondary sides insulated, in order to prevent interference of the power supply circuit when connecting the external input circuit. Be sure not to use an auto-transformer.



### 3.8 For Output connection

● Transistor output (Main unit)

- Since the transistor output is insulated from the internal circuit by a photo-coupler, it can be used both as a plus common and minus common.




- Wire up to 100m for output connection.

### 3.9 RS485 communication


- When using shielded cable for the RS485 transmission line, ground one end. Use a class D dedicated earth for grounding. Do not share a ground with other earth lines. (Fig.1)
- Be sure to connect with daisy chain the RS485 transmission line between each unit. Do not use a splitter. (Fig.2)
- With a terminal station, RS485 (E) (No.10) and RS485 (-) (No.9) should be shorted.

\*E terminal is not SG (signal ground) terminal. Do not ground shielded cable.

(Fig.1)



(Fig.2)



**Recommended Cable**

Use the transmission cables shown below for Eco-POWER METER RS485 communication system.

Cable	Conductor		Insulator		Cable diameter	Applicable cable
	Size	Resistance (at 20°C)	Material	Thickness		
Twisted-pair with shield	1.25 mm <sup>2</sup> (AWG16) or more	Max.16.8 Ω/km	Polyethylene	Max. 0.5 mm	Approx. 8.5 mm	HITACHI KPEV-S 1.25 mm <sup>2</sup> × 1P Belden Inc. 9860
	0.5 mm <sup>2</sup> (AWG20) or more	Max.33.4 Ω/km	Polyethylene	Max. 0.5 mm	Approx. 7.8 mm	HITACHI KPEV-S 0.5 mm <sup>2</sup> × 1P Belden Inc. 9207
VCTF	0.75 mm <sup>2</sup> (AWG18) or more	Max.25.1 Ω/km	PVC	Max. 0.6 mm	Approx. 6.6 mm	VCTF 0.75 mm <sup>2</sup> × 2C (JIS)

Cable	Section
Twisted-pair with shield	
VCTF	

**Notes**

- 1) Use shielded type twist cables.
- 2) Use only one type of the transmission cables. Do not mix different types of the cables.
- 3) Use twist pair cables under a bad noise environment.

### 3.10 Backup battery (only for KW2G-H SD card type)


Install the included battery (Model No.:AFPG804) before use. Be careful of the short circuit of battery contacts (metal part).

When starting to use the unit first or passing long time with battery off, initialize the memory. If you don't initialize it, it doesn't log correctly.


#### ●How to connect / replace the battery

##### 1) Open the battery cover.

Remove the connector from the slit on the rear.




##### 2) Connect battery to the connector.




##### 3) Put the connector and lead wire into the case.

Bend the lead wire hear to put into the case easily.



##### 4) Put the battery in and close the cover.



#### <Note>

Battery life is about 2 years; we recommend exchanging battery about 2 years from the beginning of the use. When battery has abnormal or battery power is reduced, 'BATT' is blinking in the upper line. Power off the unit and replace the battery according to the procedures in 2 minute.

In addition, be sure to save logging data in SD memory card before replacing battery. It may lose the internal memory.

Please throw away the replaced battery according to the instruction of your area.

### 3.11 Low Voltage Directive

When using in the application conforming to EN61010-1/IEC61010-1, make sure to satisfy the following conditions.

- (1) Pulse output part and communication part secure only basic insulation. In order to secure reinforced (double) insulation demanded by EN61010-1/ IEC61010-1, secure basic insulation or more with load side for output part and secure basic insulation or more with communication system side for communication part.
- (2) Provide the voltage input part with an EN60947-1 or EN60947-3 compliant circuit breaker. The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- (3) Use a wire with basic insulation or more for a wire cramped (or connected) CT.

#### 【Environmental conditions】

- Overvoltage category II, Pollution degree 2
- Indoor use
- An ambient temperature of -10 to 50°C
- An ambient non-condensing humidity of 30 to 85%RH (at 20°C)
- Altitude of 2000m or less

#### 【Mount the product in a place with】

- A minimum of dust, and an absence of corrosive gases
- No flammable, explosive gasses
- Few mechanical vibrations or shocks
- No exposure to direct sunlight
- No large capacity electromagnetic switches or cables through which large current is flowing

## Chapter 4 Settings

### 4.1 Setting for KW2G main unit and Expansion unit (power measurement)

When power on, [M] and connected expansion unit number turn on the display of main unit. After that, it displays the monitor display (measuring value).

#### 【Basic setting to measure】

When wiring Eco-POWER METER and CT and setting mode 1 after power on, Eco-POWER Meter can measure the electric power. In order to use the other functions, set mode2, 3 and 4 according to your use.

Mode 1: Mode for setting about power measurement

Mode 2: Mode for setting about pulse measurement


Mode 3: Mode for setting about serial communication (RS485)

Mode 4: Mode for setting about optional function

In addition, when connecting main unit and expansion units, there are some items that are necessary to set each unit.

#### 【Unit change】

Before setting, press <MODE> to shift display of main unit (M) and expansion units (1 to 7) to set.




Setting flow chart for KW2G main unit and Expansion unit (power measurement)

Mode 1...Mode for setting each parameter for power measurement

The mode with ★ is not displayed when it shift to expansion units.


Select M (Main unit) before the settings.

The mode with ★ is not displayed when the software version doesn't support it.



Press <MODE> to return Monitor.

●When select except 'Value' with Unit for pulse output setting mode



- Mode 2...Mode for setting of each parameter for pulse measurement (only for main unit)
- Mode 3...Mode for setting of each parameter for serial communication (common)
- Mode 4...Mode for setting of each parameter for optional function


**When it shifts to expansion unit, mode 2 and mode 3 are not displayed.**

**Only version check mode is available in mode 4.**

Select **[M]** (Main unit) before the settings.

With version check mode (※), the version of each unit can be checked.

**The mode with ☆ is not displayed when the software version doesn't support it.**



## 4.2 Setting for KW2G-H main unit SD card type and Expansion unit (power measurement)

When power on, [M] and connected expansion unit number turn on the display of main unit. After that, it displays the monitor display (measuring value).

### 【Basic setting to measure】

When wiring Eco-POWER METER and CT and setting mode 1 after power on, Eco-POWER Meter can measure the electric power. In order to use the other functions, set mode2, 3 and 4 according to your use.

Mode 1: Mode for setting about power measurement

Mode 2: Mode for setting about pulse measurement

Mode 3: Mode for setting about serial communication (RS485)


Mode 4: Mode for setting about optional function

In addition, when connecting main unit and expansion units, there are some items that are necessary to set each unit.

### 【Unit change】

Before setting, press <MODE> to shift display of main unit (M) and expansion units (1 to 7) to set.

During the option mode is displayed, it shifts to only expansion units (power measurement).




Setting flow chart for KW2G-H SD card type and Expansion unit (power measurement)


Mode 1...Mode for setting each parameter for power measurement

The mode with ★ is not displayed when it shift to expansion units.

Select **M** (Main unit) before the settings.



●When select except 'Value' on Unit for pulse output setting mode




- Mode 2...Mode for setting of each parameter for pulse measurement
- Mode 3...Mode for setting of each parameter for serial communication
- Mode 4...Mode for setting of each parameter for optional function
- Mode 5...Mode for setting of year-month-date and time

**When it shifts to expansion unit, mode 2, mode 3 and mode 5 are not displayed. Only version check mode is available in mode 4.**

Select **[M]** (Main unit) before the settings.

With version check mode (※), the version of each unit can be checked.

**The mode with ☆ is not displayed when the software version doesn't support it.**



## ◆ Initial value list (Main unit / Expansion unit (power meter))

Mode 1		Mode 2																	
Item	Initial value	Item	Initial value																
Phase/Wire system	1P2W	Pulse input type	PULSE																
CT type	50	Max. measurement speed	50000																
Primary side current of CT	5																		
VT	1.00	Prescale	1.000																
Shift average frequency	8	<table border="1"> <thead> <tr> <th colspan="2">Mode 3</th> </tr> <tr> <th>Item</th> <th>Initial value</th> </tr> </thead> <tbody> <tr> <td>Protocol</td> <td>MEWTOCOL</td> </tr> <tr> <td>Station number</td> <td>1</td> </tr> <tr> <td>Transmission speed</td> <td>19200</td> </tr> <tr> <td>Transmission format</td> <td>8bit-o</td> </tr> <tr> <td>Stop bit</td> <td>1</td> </tr> <tr> <td>Response time</td> <td>1</td> </tr> </tbody> </table>		Mode 3		Item	Initial value	Protocol	MEWTOCOL	Station number	1	Transmission speed	19200	Transmission format	8bit-o	Stop bit	1	Response time	1
Mode 3																			
Item	Initial value																		
Protocol	MEWTOCOL																		
Station number	1																		
Transmission speed	19200																		
Transmission format	8bit-o																		
Stop bit	1																		
Response time	1																		
Simple measuring	OFF																		
Simple voltage	110.0																		
Simple PF	1.00																		
Cutoff current	0.1																		
Current for time measurement 1 *2 *3	50.0																		
Current for time measurement 1 *2 *3	100.0																		
Unit for pulse output	0.001																		
Pulse output width	100																		
Power alarm	9999.99																		
Current alarm	100.0																		
Stand-by alarm 1	100.00																		
Stand-by alarm 2	0																		
Preset value	0																		
General-purpose output	PL-L																		
General-purpose output ON-time	0.1																		
General-purpose output OFF-time	0.1																		
Electricity rate	10.00																		
Conversion factor	0.410																		

Mode 4		Mode 5	
Item	Initial value	Item	Initial value
Auto-off	0	Calendar timer *1	2000 Jan. 1 00:00
Saved file type FILE1 *1	ON		
Saved file type FILE2 *1	ON		
Saved file type FILE3 *1	ON		
Log cycle *1	60		

\*1 Only for KW2G-H SD card type (AKW2020G)

There is no display with KW2G standard type (AKW2010G).

\*2 It can set to the only one expansion unit.

There is no display with the expansion unit (analog input) (AKW2182).

\*3 There is no display with the expansion unit (pulse input) (AKW2152G).


### 4.3 Setting Mode Explanation for Main unit and Expansion unit (power measurement)

- The value with under line ‘   ’ is initial setting among each setting value. ☆ Set before measurement.
- Some modes are only for KW2G-H SD card type. Refer to 4.1 and 4.2.
- The mode with (※) mark can be set to each unit.

#### 4.3.1 Mode 1

(Mode for setting each parameter for power measurement.)

Mode1 Setting flow chart



**Phase/Wire system setting mode (※)**

**Mode defines phase and wire system to measure.**

- Select from Single-phase 2-wire / Single-phase 3-wire / Three-phase 3-wire.
- Select the system of the measured load.

*\*When the system is not matched with the measure system, it doesn't measure correctly.*

Press <ITEM/Δ> to change.

↓ <SET>

**CT type setting mode (※)**

**Mode defines input current type of the dedicated CT.**

- Select from the type of 5A/50A/100A/250A/400A.
- When the secondary current of CT is 5A, select '5A'.

Press <ITEM/Δ> to change.

↓ <SET>

**Primary side current of CT setting mode (※)** \*It is only when '5A' is selected on CT type setting mode.

**Mode defines primary side current when measuring by combination with another CT, its secondary current of 5A.**

**It is possible to use as the second step for combination with another CT by selecting '5A' in the CT type setting mode. In this case, it is necessary to set the primary side current.**

- Primary side current of the measured CT can be set the range of 1 to 4000 (Initial 5).
- When connecting 5A CT directly and measure with 5A range, set to '5'.

Ex.) If primary current of measured CT is 400A (secondary side is 5A), set to '400'.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.

	Increase
	Decrease

↓ <SET>

**VT ratio setting mode**

**Mode defines voltage input method to the main unit, input voltage directly or uses a voltage transformer (VT) (over 440V system).**

- It can be set the range of 1.00 to 99.99.
- '1.00' should be set when voltage input directly without connecting VT.
- '1.01 to 99.99' should be set when VT is used to input voltage.

Ex.) If the VT is 440/110, set to '4.00'.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.



(1.00 to 99.99)

	Increase
	Decrease

↓ <SET>

**Shift average frequency setting mode (※)**

**Mode defines shift average frequency for instantaneous value.**

When unevenness of the measurement value is large, you can suppress the unevenness by setting bigger average frequency.

In order to measure in detail including unevenness, select '0'.

- Select from 0 / 2 / 4 / 8 / 16.

Setting of the shift average frequency reflects to electric power, current and voltage.


Press <ITEM/Δ> to change 8 ⇒ 16 ⇒ 0 ⇒ 2 ⇒ 4.




→



→



→




→



↓ <SET>

Ex.: When selecting '4'



**Simple measuring setting mode**


**Mode defines that you use simple measuring function or not.**  
 Select 'ON' in order to use simple measuring function.

Press <ITEM/Δ> to change OFF ⇔ ON.



OFF





ON

↓ <SET>

**Simple voltage setting mode** \*It is only when 'ON' is selected on Simple measuring setting mode.

**Mode defines voltage value to use for simple measuring.**

- It can be set the range of 0.0 to 9999.9V (initial: 110.0V).
- Ex.) If it is 220V, set to '220.0'.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.



(0.0 to 9999.9, initial: 110.0)

	Increase
SET + 	Decrease

↓ <SET>

**Simple PF setting mode** \*It is only when 'ON' is selected on Simple measuring setting mode.

**Mode defines power factor to use for simple measuring.**

- It can be set the range of 0.00 to 1.00 (initial: 1.00).
- Ex.) If it is 0.9, set to '0.90'.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.



(0.00 to 1.00)

	Increase
SET + 	Decrease

↓ <SET>

**Cutoff current setting mode (※)**

**Mode defines load current that does not measure (Cutoff current).**  
**Use to avoid miss-measurement by wiring or induction noise at no-load.**  
**0.00kW is displayed for instantaneous electric power, 0.0A is displayed for current. Integrated electric power is not added.**

- It can be set the range of 0.1 to 50.0%.
- ex) When set to 10.0, current (=power) under 10.0%F.S is not added.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.



(0.1 to 50.0)

	Increase
SET + 	Decrease

↓ <SET>

**Current for time measurement 1 ☆**

**Mode defines for time measured current. It measures OFF-time and ON-time1 by setting value.**

• It can be set the range of 0.1 to 100.0%F.S. (initial 50.0)

Ex) When 50.0 is set, the current exceeds 50.0%F.S. is measured as ON-time, the current under 50.0%F.S. is measured as OFF-time.

\*For 1P2W, measured current is the current of CT1 for ON-time1(1)(1.HMA1) and CT2 for ON-time1(2)(2.HMA1)

For 1P3W and 3P3W, measured current is the current of CT1.

It can't be set as CUTA > 1.HM-A.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.



(0.1~100.0) (initial 50.0)

	Increase
	Decrease

↓ <SET>

**Current for time measurement 2 ☆**

**Mode defines for time measured current. It measures ON-time1 and ON-time2 by setting value.**

• It can be set the range of 0.1 to 100.0%F.S.

Ex) When 70.0 is set, the current exceeds 70.0%F.S. is measured as ON-time1, the current under 70.0%F.S. is measured as OFF-time.

\*For 1P2W, measured current is the current of CT1 for ON-time2(1)(1.HMA2) and CT2 for ON-time2(2)(2.HMA2)

For 1P3W and 3P3W, measured current is the current of CT1.

It can't measure ON-time1 when it set as 1.HM-A=2.HM-A.

It can't be set as 1.HM-A > 2.HM-A.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.



(0.1~100.0)

	Increase
	Decrease

↓ <SET>

**Unit for pulse output setting mode**

**Mode defines unit used for pulse output. It defines the unit of integrated electric power for 1-pulse output.**

- Select from 0.001/0.01/0.1/1/10/100kWh /AL-P/AL-C/AL-S/Cnt/OUT/Error.

When one of the '0.001/0.01/0.1/1/10/100' [kWh] is set, one pulse is output at reaching the setting value. When 'AL-P(Power alarm)' is set, alarm is output at the time when instantaneous electric power is over the setting value. When 'AL-C(Current alarm)' is set, alarm is output at the time when current is over the setting value. When 'AL-S(Stand-by alarm)' is set, alarm is output at the time when current is under the setting value and it passes the setting time. When 'Cnt(Count output)' is set, it output at the time when count value reaches preset value set by preset value setting mode. When 'OUT' is set, it controls the output via communication.

When 'Error (Error alarm)' is set, alarm is output When SD memory card writing error, battery shortage, communication error between main unit and expansion unit.

Press <ITEM/Δ>,<SET>+<ITEM/Δ> to change.

↓ <SET>

**Pulse output width setting mode** \*It is only when 'electric power value' is selected on unit for pulse output setting mode.

**Mode defines pulse output width. It defines the width for 1 pulse.**

- It is set the range of 1 to 100ms.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.

ITEM/Δ	Increase
SET + ITEM/Δ	Decrease

↓ <SET>

**Power alarm setting mode** \*It is only when 'AL-P' is selected on unit for pulse output setting mode.

**Mode defines instantaneous electric power used for alarm output.**

- It is set the range of 0.00 to 9999.99kW.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

ITEM/Δ	Increase
SET + ITEM/Δ	Decrease


↓ <SET>

**Current alarm setting mode** \*It is only when 'AL-C' is selected on unit for pulse output setting mode.

**Mode defines the ratio of current used for alarm output. (Ratio for the rated current)**

- It is set the range of 0.1 to 100.0%.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

 (0.1 to <u>100.0</u> )	 Increase
	 Decrease

↓ &lt;SET&gt;

**Stand-by alarm setting mode 1** \*It is only when 'AL-S' is selected on unit for pulse output setting mode.

**Mode defines the ratio of current used for threshold value to judge stand-by power. (Ratio for the rated current)**

- It is set the range of 0.1 to 100.0%.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

 (0.1 to <u>100.0</u> )	 Increase
	 Decrease

↓ &lt;SET&gt;

**Stand-by alarm setting mode 2** \*It is only when 'AL-S' is selected on unit for pulse output setting mode.

**Mode defines the time used for threshold value to judge stand-by power.**

- It is set the range of 0 to 9999min.

When '0' is set, alarm is always output at the time when judging the stand-by power.  
 When '1 to 9999' is set, alarm is output at the time when passing the setting time with the stand-by power.

The alarm can be reset by pressing <SET> with the instantaneous electric power display. After reset the alarm, start to monitor the stand-by power again.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

 ( <u>0</u> to 9999 min.)	 Increase
	 Decrease

↓ &lt;SET&gt;


**Preset value setting mode** \*It is only when 'Cnt' is selected on unit for pulse output setting mode.

**Mode defines count value used for output.**

- It is set the range of 0(0.000) to 999999(999.999).

\*The range differs according to the pre-scale set by pre-scale setting mode.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

 ( <u>0</u> to 999999)	 Increase
	 Decrease

↓ &lt;SET&gt;

**General-purpose output setting mode** \*It is only when 'OUT' is selected on unit for pulse output setting mode.

**Mode defines a type of general-purpose output.**  
 • Select from PL-L/ PL-F/ PL-O.  
 'PL-L (Level output)' When the designated data register is 1(ON), it output.  
 'PL-F (Repeat cycle output)' When the designated data register is 1(ON), it repeats on and off according to the setting.  
 'PL-O (One-shot output)' When the designated data register is 1(ON), it output one time and after passing the setting time, it turns off the output.  
 \*It doesn't work with the on-time and off-time set to under 0.1s.  
 Press <ITEM/Δ>, <SET>+<ITEM/Δ> to change

**Output ON-time setting mode (※)** \*It is only when 'PL-F' or 'PL-O' is selected on general-purpose output setting mode.

**Mode defines ON-time of output for 'PL-F' and 'PL-O'.**  
 • It is set the range of 0.1 to 10.0 sec.  
 Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.

**Output OFF-time setting mode (※)** \*It is only when 'PL-F' is selected on general-purpose output setting mode.

**Mode defines OFF-time of output for 'PL-F'.**  
 • It is set the range of 0.1 to 10.0 sec.  
 Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.

**General-purpose output test mode (※)**




**It tests the general-purpose output.**  
 • Select from OFF/ON.  
 'ON' ; It can test whether it output correctly or not.  
 'OFF'; It doesn't test the output.  
 \*Note that it will output when select 'ON' with <ITEM/Δ>.  
 Press <ITEM/Δ> to change.

**Electricity charge setting mode**

**Mode defines electricity charge ratio used as a standard per 1kWh.**

- It can be set the range of 0.00 to 99.99 /1kWh. (Initial 10.00)

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

	(0.00 to 99.99, initial: <u>10.00</u> )	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">Increase</td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">Decrease</td> </tr> </table>		Increase		Decrease
	Increase					
	Decrease					

↓ <SET>

**Conversion factor setting mode**

**Mode defines conversion factor of carbon dioxide used as a standard per 1kWh.**

- It can be set the range of 0.000 to 9.999/1kWh. (Initial 0.410)

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

	(0.000 to 9.999, initial: <u>0.410</u> )	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">Increase</td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">Decrease</td> </tr> </table>		Increase		Decrease
	Increase					
	Decrease					


↓ <SET>

Monitor

4.3.2 Mode 2

(Mode for setting of each parameter for pulse measurement: Mode 2 is for the functions of main unit.)

Mode2 Setting flow chart



**Pulse input type setting mode ☆**

**Mode defines input type of input signal with pulse input terminal to use for pulse count or maintenance time.**

Use it when you don't measure either OFF-time nor ON-time, for example the load is under maintenance.

- Select from PULSE/MAINTE
- PULSE: It counts ON-signal as a pulse count
- MAINTE: It counts ON-signal as maintenance time.

*\*Note that it doesn't measure pulse count, OFF-time, ON-time during it measures maintenance time.*

Press <ITEM/Δ> to change..



PULSE





MAINTE

↓ <SET>

**Max. counting speed setting mode**

**Mode defines max. counting speed.**


- Select from 30Hz/50kHz

Press <ITEM/Δ> to change..



50000(50kHz)





30(30Hz)

↓ <SET>

**Pre-scale setting mode**

**Mode defines pre-scale value used for changing count value.**

- It can be set the range of 0.001 to 100.000. (Initial 1.000)
- The position of decimal point set with this mode is applied to count value and preset value.  
ex) When '0.010' (Last 2-digit) is set, the decimal point of count value and preset value has 2 digit under decimal point.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.



(0.001 to 100.000, initial: 1.000)

	Increase
	Decrease


↓ <SET>

Monitor

### 4.3.3 Mode 3

(Mode for setting of each parameter for serial communication:  
 Mode 3 is common settings for main unit and expansion unit.)

#### Mode3 Setting flow chart



**Protocol setting mode**  
**Mode defines communication protocol of main unit via serial communication (RS485).**  
 • Select from MEWTOCOL / MODBUS(RTU).  
 Press <ITEM/Δ> to change.

↓ <SET>

**Station number setting mode**  
**Mode defines an individual station no. for each unit when two or more units communicate via serial communication (RS485).**  
 • It can be set the range of 1 to 99.  
 Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

↓ <SET>

**Transmission speed setting mode**  
**Mode defines serial communication (RS485) transmission speed. Define the transmission speed according to the master's (PLC etc.).**  
 • Select from 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200 [bps].  
 Press <ITEM/Δ>,<SET>+<ITEM/Δ> to change.

↓ <SET>

**Transmission format setting mode**

**Mode defines serial communication (RS485) transmission format (Data length, Parity). Define the transmission format according to the master's (PLC etc).**

- Select from 8bit-o/7bit-n/7bit-E/7bit-o/8bit-n/8bit-E.
- 'n (none)' means parity is not available.
- 'E (Even)' means parity is even number.
- 'o (odd)' means parity is odd number.
- \*With MODBUS (RTU) protocol, it works only with 8bit.

Press <ITEM/Δ>, <SET>+<ITEM/Δ> to change.

n: not available  
E: even number  
o: odd number

↓ <SET>

**Stop bit setting mode**

**Mode defines serial communication (RS485) stop bit.**

- Select from 1 / 2.

Press <ITEM/Δ> to change.

↓ <SET>

**Response time setting mode**

**Mode defines serial communication (RS485) response time of main unit.**

**When command is received, it sends response after setting response time passes.**

- It can be set the range of 1 to 99 ms.
- \*For using Data Logger Unit (DLU) or Data Loggert unit(DLL) as a master, the response time of DLU is under 1.1ms at 19200bps, set 5ms or more for response time of Eco-POWER METER.

Set it using <ITEM/Δ>, <SET>+<ITEM/Δ>.


↓ <SET>

Monitor

4.3.4 Mode 4

(Mode for setting of each parameter for optional function)  
 The mode with (※) mark can be set to each unit.

MODE4 Setting flow chart



**Auto-off setting mode**

**Display LCD turns off automatically when there is no key operation for a long time.**

- Off time can be set the range of 0 to 99min.
- '0' should be set if you want to turn always light on.
- '1 to 99' should be set if you want to turn light off at setting time.
- After turns off the LCD, any key operation makes it turns on.

Set it using <ITEM/Δ>,<SET>+<ITEM/Δ>.

 ( 0 to 99 min.)	 Increase
	 Decrease

↓ <SET>

**Version check mode (※)**

**Mode to check version of the software.**  
 It displays version of the software.



↓ <SET>

**Initialize memory of main unit** \*Only KW2G-H

**Use to initialize memory of main unit and delete the saved logging data (measured data).**  
 Use when you want to delete the logging data such as changing a measured load and so on.

- Select ON and press <SET>, it initialize memory of main unit. Any key doesn't work during initializing. Initial: OFF

\*Initialize memory of main unit when start using the unit or when it continues power off or no battery.  
When it is not initialized, it may not display log data correctly.  
\*It doesn't reset the displayed measuring data.

Press <ITEM/Δ> to change.  
 Select 'ON' and press <SET> and memory is initialized.

		
OFF		ON

↓ <SET>

**Saved file type selection mode** **\*Only KW2G-H**

**Mode defines file types to write to SD memory card.**  
 Refer to Chapter 5.4 for the detail contents of each file.

- Select ON and press <SET> for each type 1, 2 and 3, it writes to SD memory card.
- Select OFF and press <SET> for each type 1, 2, and 3, it doesn't write to SD memory card.

Type1: Instantaneous value file    Type2: Difference value file  
 Type3: Instantaneous value in detail file

- Log cycle is fixed to 15-min for type 1 and type 2.
- Logging data will be saved regardless of the setting.

In order to write to SD memory card with the displayed file type, set to 'ON'.  
 There are 3 types and you can select ON or OFF for each type.

---

T1 (type1): Instantaneous value file    ON: Write data of the latest 8 days.  
 OFF: Not write



ON





OFF

\*Cycle is fixed to 15-minute.

↓ <SET>

T2 (type2): Difference value file    ON: Write data of the latest 8 days.  
 OFF: Not write



ON





OFF

\*Cycle is fixed to 15-minute.

↓ <SET>

T3 (type3): Instantaneous detailed value file    ON: Write the latest 720 records (max.).  
 OFF: Not write



ON





OFF

↓ <SET>

**Log cycle setting mode** **\*Only KW2G-H**

**Mode defines save cycle for type 3 file.**  
 • Select from 60 / 1 / 5 / 10 / 15 / 30 (min).  
 It saves measured data with selected cycle.

Press <ITEM/Δ> to change.



60-minute





1-minute





5-minute





10-minute





15-minute





30-minute



↓ <SET>

**Monitor**

4.3.5 Mode 5

(Mode for setting of year-month-day and time)

Mode 5 Setting flow chart




4.3.6 Remove SD memory card \*Only KW2G-H

**You can remove SD memory card safely.**

- Press <SET> during 'SD EJECT' is displayed, and stop writing to SD memory card. When 'SD ok' is appeared, you can remove SD memory card.
- During 'SD ok' is displayed, it doesn't write log data to SD memory card.
- If SD memory card is removed during 'SD ok' is displayed, it returns to monitoring display.
- 'SD EJECT' is displayed only when SD memory card is inserted.
- \* Do not remove SD memory card until when 'SD ok' is displayed.

Remove SD memory card flow chart




## Chapter 5 Various Functions

### 5.1 LOCK mode

It is the mode makes all keys unable. Use when you want to fix one of the measurement displays (For all displays). In this mode, you can not input by any keys.

When you press <SET> continuously for about 3sec., the 'LOCK' lights and all keys become locked (pressing them will have no effect).


Press <SET> continuously for about 3sec. again to release Lock mode. The 'LOCK' indicator goes off and the lock mode is released (unlocked).



### 5.2 Pulse output function

Pulse output function is only for the main unit. Refer to the mode 1 setting for the way to set.

'OUT' is lighting when pulse output.



#### 5.2.1 Output depends on integrated electric power

Set the unit for pulse output (0.001/0.01/0.1/1/10/100kWh) and pulse output (transistor output) turns on every time when integrated electric power reaches the unit. (Pulse width: set with setting mode)

#### 5.2.2 Instantaneous electric power alarm

When it exceeds the setting instantaneous electric power, pulse output (transistor output) turns on in order to notice. When it falls below, the output turns off.

#### 5.2.3 Current alarm

When it exceeds the setting current ratio, pulse output (transistor output) turns on in order to notice. When it falls below, the output turns off.

#### 5.2.4 Stand-by power alarm


When it detects stand-by power (current) of the measured load, pulse output (transistor output) turns on in order to notice.

Set current (C) and stand-by time (T) to judge stand-by power.


When the measured load is satisfied the setting conditions, pulse output (transistor output) turns on in order to notice.

When it exceeds the setting value, it turns off and reset it.

You can reset the alarm by pressing <SET> with the instantaneous electric power display.



(Working flow chart)



#### 5.2.5 Output depends on count value

Set the preset value and pulse output (transistor output) turns on the time when count value reaches the preset value.

Refer to the next in detail.



### 5.4 General-purpose output function

Using this general-purpose output function, it turns on or off the output by writing 0 (OFF) or 1(ON) to the designated data register via communication. When it turns on, data register is started with 0 (OFF).


\*It doesn't work with the on-time and off-time set to under 0.1s.

● Operation mode

• Level output

When the designated data register is 1(ON), it turns on the output.


When the designated data register is 0(OFF), it turns off the output.



• Repeat cycle output

When the designated data register is 1(ON), it starts a repeat cycle operation.


During a repeat cycle operation, it repeats on and off according to the setting output ON-time ( $t_1$ ) and output OFF-time ( $t_2$ ).



• One-shot output


When the designated data register is 1(ON), it turns on the output.

After passing the setting output ON-time ( $t_1$ ), the data register will be 0 (OFF) and it will turn off the output. Even if it writes 1(ON) before passing the setting output ON-time, it rejects the writing. (It doesn't reset the setting ON-time.)



## 5.5 Hour meter function

(KW2G/KW2G-H Main unit Ver.1.10 or more)



- When load current is under the setting current for time measurement (HM-A), it measures as OFF-time. When load current is exceeded to the setting current for time measurement (HM-A), it measures as ON-time. Current for time measurement (HM-A) is set to under cutoff current (CUTA), all current is measured as OFF-time.

- Maintenance time

It measures maintenance time. Use it when you don't measure either OFF-time nor ON-time, for example the load is under maintenance.

It measures ON signal input with the pulse input terminal as maintenance time. Actual work time is the total time of ON-time2, ON-time1 and OFF-time.

Hour meter function can be used only with main unit and one expansion unit.

2 or more expansion units can't be used hour meter function.

- Ratio of ON-time

It displays ratio of ON-time calculated with actual work time and ON-time as below.

[Calculation method of Ratio of ON-time]

Ratio of ON-time1 =  $\text{ON-time1} / (\text{actual work time} - \text{Maintenance time}) \times 100(\%)$

Ratio of ON-time2 =  $\text{ON-time2} / (\text{actual work time} - \text{Maintenance time}) \times 100(\%)$

However, for ratio of ON-time, it uses measuring value inside every 1 sec., therefore it may be different when you compare with displayed OFF-time, ON-time1, ON-time2, maintenance time and actual work time.

## 5.6 Log data writing function

This is the function that it writes the measurement data to SD memory card.

Be sure to format your SD memory card before using.

There are 3 kinds of file to write.

File type 1: Instantaneous value (Saved cycle: fixed 15-minute)

File type 2: Difference value (Saved cycle: fixed 15-minute)

File type 3: Instantaneous detailed value (Saved cycle: select from 1/10/15/30/60 minutes)

### 5.6.1 In case that SD memory card is always inserted to card slot

During inserting SD card to the card slot, it writes data at the time as below.

It writes the data every time to update.

Normally, we recommend using this with inserting SD memory card.

<Note> Set to 'ON' for the file type to write with 'Saved file type selection mode' (mode 4).

<Timing of creating files>

File type 1, 2	00:00 every day
File type 3	Same timing as log cycle

<Guide for data capacity (1-day: 24 hours)>

File type 1	About 100kB
File type 2	About 32kB
File type 3	About 1.4MB (Log cycle: 1 min)

\*Recordable data capacity is depend on the SD memory card.

If there is no space to write, it will not write data after that and error is shown on the display.

### 5.6.2 In case that you insert SD memory card

When measuring data are logged in the unit memory, the following data can be written.

File type 1, 2	The latest 8-day data
File type 3	The latest 720 records max. (12-hour data: Saved cycle 1min.)

It writes only the latest data. When it reaches the max records, it will overwrite from the oldest data. It doesn't differ according to the numbers of main unit and connected expansion unit.


<Guide for data capacity (Max. capacity for one-time writing)>

Max. data capacity for all file type	About 1.8MB (Writing time: about 25 minutes)
File type 1 only	About 800kB
File type 2 only	About 250kB
File type 3 only	About 700kB

◇How to write the latest data

(Power monitoring mode)


- (1) Set 'ON' for file type to save with saved file type selection mode (mode 4).
- (2) Shift to power monitoring mode display.
- (3) Insert SD memory card.
- (4) It writes data according to the setting of saved file type selection mode.




## ◇How to write data of the 1 day

- (1) Set 'ON' for file type to save with saved file type selection mode (mode 4).  
(Available only type 1 and type 2)
- (2) Shift to display 'Daily integrated electric power' in option mode. (fig.1)
- (3) Select date to write.
- (4) Insert SD memory card.
- (5) It writes the measuring data of the displayed month with file type set to 'ON'.

(fig.1)



(fig.2)



<ex.> In case that you'd like to write data of 10 March:

- (1) Shift to the display on the right (upper: D10) by using <SET> and <ITEM/Δ>.
- (2) Insert SD memory card.
- (3) It writes the data of 10 March.

## &lt;Notice&gt;

Be sure to insert the direction of SD memory card correctly.  
When it is inserted wrong direction, the unit or memory card may be damaged.  
Do not move the inserted memory card, or the unit or memory card may be damaged.  
Do not insert an unsupported memory card.

After writing data and removing SD memory card, insert a dummy card to protect in order to avoid dust or something else.

Do not turn off the power during inserting SD memory card, or the unit or memory card may be damaged.


## &lt;Display during writing&gt;

'SD ACCESS' is displayed during writing.


After completing the writing, shift to monitor display.

When there isn't enough capacity in SD memory card or SD memory card is unwritable, error display will appear alternately.


During writing



Display of writing error




Alternately





## &lt;Remove SD memory card&gt;

Remove SD memory card according to the instructions.  
Remove it with SD memory card remove display.

Removing SD memory card



OK removing SD memory card

Remove  
SD memory card

## &lt;Notice&gt;

During 'SD ACCESS' is displayed, do not remove the memory card.  
It may cause damage of data in memory card or damage of memory card or stop working.  
In addition, during writing, it may not be able to measure nor communicate.

5.6.3 Unit memory

During measurement, measuring data is saved in the unit memory.  
However, when it reaches the maximum capacity, the older data will be overwritten.  
You can initialize the unit memory. (Refer to Mode 4.)

### 5.6.4 Format for written file

Data in SD memory card is saved with the below format as csv file.

The file format, which is saved by Eco-POWER METER, is fixed.

<File type 1 (Instantaneous value)>

	A	B	(1) C	D	E	F	G	H
1	Date	Time	1	2	3	4	5	6
2			KW2G	KW2G	KW2G	KW2G	KW2G	KW2G
3			COM1[Unit No.01 No.1]	COM1[Unit No.01 No.1]	COM1[Un	COM1[Un	COM1[Un	COM1[Un
4			DT120	DT122	DT176	DT182	DT178	DT184
5			MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT
6			US32 ->FLT	JS32 ->FLT	US32 ->F	US32 ->F	US32 ->F	US32 ->F
7			kWh	kWh	kW	kW	kvar	kvar
(2) 8	2012/4/1	0:15:00						
9	2012/4/1	0:30:00						
10	2012/4/1	0:45:00						
11	2012/4/1	1:00:00						
12	2012/4/1	1:15:00						
13	2012/4/1	1:30:00						
14	2012/4/1	1:45:00						
30	2012/4/1	23:45:00						
31	2012/4/2	0:00:00						

(1) Device information	(row 1)	Logging data number
	(row 2)	KW2G Model name
	(row 3)	COM1[Unit No.01 No.1] Station number (based on the unit setting)
	(row 4)	DT120 Target address (main/expansion unit)
	(row 5)	MOMENT Shows 'instantaneous value'
	(row 6)	US32 -> FLT Unsigned integer 32 bit S32 -> FLT Signed integer 32 bit US16 -> FLT Unsigned integer 16 bit S16 -> FLT Signed integer 16 bit
	(row 7)	kWh Unit (based on the target address)
(2) Logging trigger	Timing to log data: 15 minutes fixed (00,15,30,45 of each hour)	
(3) Record number	Record number for 1 file: 96 records fixed Timing of creating file: 00:00:00 every day	
(4) Logging data	Logging data of the same timing: 22 data (fixed) From column C to AC Integrated electric power(1), Integrated electric power(2), Instantaneous electric power: active(1), active(2), reactive(1), reactive(2), apparent(1), apparent(2) R-current, N/S-current, R/T-current, R(RS)-voltage, RT-voltage, T(TS)-voltage, Power factor(1), Power factor(2), Frequency, Count value CH0 digital conversion value, CH1 digital conversion value, CH0 pulse count value, CH1 pulse count value	

\*'Integrated electric power' is logged with the unit of 0.01kWh.  
It doesn't log it with the unit of 0.001kWh.

<File type 2 (Difference value)>

(1) → (4)

	A	B	C	D	E	F	G	H
1	Date	Time	1	2	3	4	5	6
2			KW2G	KW2G	KW2G	KW2G	KW2G	
3			COM1[Unit No.01]	COM1[Unit No.01]	COM1[Unii	COM1[Unii	COM1[Unii	COM1[Unii
4			DT100	DT122	DT154	DT194	DT196	
5			DIFFERENCE	DIFFERENCE	DIFFEREN	DIFFEREN	DIFFERENCE	
6			US32 ->FLT	US32 ->FLT	US32 ->FL	US32 ->FL	US32 ->FLT	
7			kWh	kWh	CNT	pulse	pulse	
8	2012/4/1	0:00:00						
9	2012/4/1	0:15:00						
10	2012/4/1	0:30:00						

(2) ↻ (3) ↓

(1) Device information	(Row 1)	Logging data number
	(Row 2)	KW2G Model name
	(Row 3)	COM1 Station number (based on the unit setting)
	(Row 4)	DT120 Target address (only the beginning)
	(Row 5)	DIFFERENCE Shows 'difference value'
	(Row 6)	US32 -> FLT Unsigned integer 32 bit
	(Row 7)	kWh Unit (based on the target address)
(2) Logging trigger	Timing to log data: 15 minutes fixed (00,15,30,45 of each hour)	
(3) Record number	Record number for 1 file: 96 records fixed Timing of creating file: 00:00:00 every day	
(4) Logging data	•Record in 1 file regardless f the type	
	• '-' is recorded for immeasurable items	
	Logging data of the same timing: 5 data (fixed) From column C to G Integrated electric power(1), Integrated electric power(2), Count value CH0 pulse count value, CH1 pulse count value *In case of no data is the past, it will record '0'.	

\*'Integrated electric power' is logged with the unit of 0.01kWh.  
It doesn't log it with the unit of 0.001kWh.

<File type 3 (Instantaneous detailed value)>

(4) →

(1)	A	B	C	D	E	F	G	H	I	J	
	1	No.	Date time	kWh	kWh	kW	kW	kvar	kvar	kVA	kVA
(2)	2	1	2012/10/1 0:00								
	3	2	2012/10/1 0:15								
	4	3	2012/10/1 0:30								
	5	4	2012/10/1 0:45								
	6	5	2012/10/1 1:00								
	7	6	2012/10/1 1:15								
	8	7	2012/10/1 1:30								
	9	8	2012/10/1 1:45								
	10	9	2012/10/1 2:00								
	11	10	2012/10/1 2:15								
	12	11	2012/10/1 2:30								

(3) ↓

(1) Item	(row 1) Measured data (Fixed)
(2) Logging trigger	Timing to log data: 1,10,15,30,60 min. (selectable with setting mode) 1 min: 00 in every minute 10-min: 0,10,20,30,40,50 in every hour 15-min: 0,15,30,45 in every hour 30-min: 0,30 in every hour 60-min: 00 in every hour
(3) Record number	Record number for 1 file: • Depend on capacity of SD memory card (In case of inserting SD memory card) • 720 records (in case of not inserting SD memory card) File creating timing: Same as logging timing
(4) Logging data	• Record in 1 file regardless of the type • '-' is recorded for immeasurable items Logging data of the same timing: 22 data (fixed) From column C to AC Integrated electric power(1), Integrated electric power(2), Instantaneous electric power: active(1), active(2), reactive(1), reactive(2), apparent(1), apparent(2) R-current, N/S-current, R/T-current, R(RS)-voltage, RT-voltage, T(TS)-voltage, Power factor(1), Power factor(2), Frequency, Count value CH0 digital conversion value, CH1 digital conversion value, CH0 pulse count value, CH1 pulse count value


\*'Integrated electric power' is logged with the unit of 0.01kWh.  
 It doesn't log it with the unit of 0.001kWh.

5.6.5 File name and Saved folder

Files are saved in SD memory card with the below constructions.  
 <File type 1 (Instantaneous value)>

ex.) Main unit + 1 unit of expansion unit  
 When you insert SD memory card at 13:20, March 1 2012:

Folder




【Folder name】

LOG -> Fixed  
 DLU0001



【File name】

syunji\_u1(120301\_001500\_TRG).csv




year/month/day, hour/minute/second in file name is the date of the beginning record.

Condition of saved file	Recorded letter
'File write trigger' occurs.	TRG

<File type 2 (Difference value)>

When you insert SD memory card at 13:20, April 3<sup>rd</sup> 2009:



【Folder name】


LOG -> Fixed

DLU0001

Station number of Eco-POWER METER (Based on the unit setting)

【File name】

Sabun\_u0(120229\_001500\_TRG).csv




year/month/day, hour/minute/second in file name is the date of the beginning record.

Condition of saved file	Recorded letter
'File write trigger' occurs.	TRG

<File type 3 (Instantaneous detailed value)>

When you insert SD memory card at 13:00 and 14:00, March 1 2012:




## 【Folder name】


LOG -> Fixed  
Unitlog -> Fixed

## 【File name】

unitlogNo01\_u0\_20120301140000.csv



unitlogNo01\_u0\_BK20120301130000.csv



\*Every time when you insert SD memory card, the new file is saved.

If you use SD memory card with csv file on the same day, 'BK' is added to the last file name.

5.6.6 Logging data

The decimal point is saved automatically when it saves with csv format.


The first record in file type 2 is the difference value from the value when start measurement.


## Chapter 6 Display of each Value

### 6.1 Working of Monitor Display

#### 6.1.1 KW2G Main unit, Expansion unit (Power measurement)

Single-phase two-wire system






Displayed item is shifted to the other direction by pressing <ITEM/Δ> during pressing <SET>.

\*1 Display of frequency and counter is common to all units.

(1), (2) of each item means as below.

Integrated electric power (1)	Integrated electric power calculated by voltage between P1-P0 and detected current by CT1
Integrated electric power (2)	Integrated electric power calculated by voltage between P2-P0 and detected current by CT2
Instantaneous electric power (1)	Instantaneous electric power from voltage between P1 - P0 and detected current by CT1
Instantaneous electric power (2)	Instantaneous electric power from voltage between P2 - P0 and detected current by CT2
R(1)-current	Detected current by CT1
R(2)-current	Detected current by CT2
R(1)-voltage	Voltage between P1 and P0
R(2)-voltage	Voltage between P2 and P0
Electricity charge (1)	Electricity charge for integrated electric power(1)
Electricity charge (2)	Electricity charge for integrated electric power(2)
CO <sub>2</sub> Conversion value (1)	CO <sub>2</sub> Conversion value for integrated electric power(1)
CO <sub>2</sub> Conversion value (2)	CO <sub>2</sub> Conversion value for integrated electric power(2)
Power factor (1)	Power factor of Instantaneous electric power(1)
Power factor (2)	Power factor of Instantaneous electric power(2)
ON-time2 (1)	ON-time2 detected by CT1
ON-time1 (1)	ON-time2 detected by CT2
ON-time2 (2)	ON-time1 detected by CT1
ON-time1 (2)	ON-time1 detected by CT2
OFF-time (1)	OFF-time detected by CT1
OFF-time (2)	OFF-time detected by CT2
Maintenace time (1)	Maintenace time detected by CT1 Time for pulse signal is input (ON) *When 'MAINTE' is set with pulse input type setting.
Maintenace time (2)	Maintenace time detected by CT2 Time for pulse signal is input (ON) *When 'MAINTE' is set with pulse input type setting.
Actual time (1)	Actual work time detected by CT1 (Total of ON-time 2, ON-time1 and OFF-time)
Actual time (2)	Actual work time detected by CT2 (Total of ON-time 2, ON-time1 and OFF-time)
Ratio of ON-time2 (1)	Ratio of load ON-time2 detected by CT1
Ratio of ON-time2 (2)	Ratio of load ON-time2 detected by CT2
Ratio of ON-time1 (1)	Ratio of load ON-time1 detected by CT1
Ratio of ON-time1 (2)	Ratio of load ON-time1 detected by CT2

Single-phase three-wire system/Three-phase three-wire system



Displayed item is shifted to the other direction by pressing <ITEM/Δ> during pressing <SET>.


\*1 Display of frequency and counter is common to all units.


\*2 Display is changed according to the phase/wire system.

	Current	Voltage
Single-phase three-wire system	R-current, N-current, T-current	R-voltage, RT-voltage, T-voltage (P1-P0) (P1-P2) (P2-P0)
Three-phase three-wire system	R-current, S-current, T-current	RS-voltage, RT-voltage, TS-voltage (P1-P0) (P1-P2) (P2-P0)

6.1.2 KW2G-H Main unit SD card type, Expansion unit (Power measurement)

Single-phase two-wire system






Displayed item is shifted to the other direction by pressing <ITEM/Δ> during pressing <SET>.


\*1 Display of frequency and counter is common to all units.

【Outline for the Working of Option Mode Display】 only KW2G-H SD card type



By pressing <ITEM/> during pressing <SET>, it shifts date or time.  
It doesn't shift the displayed items.

Single-phase three-wire system/Three-phase three-wire system




Displayed item is shifted to the other direction by pressing <ITEM/Δ> during pressing <SET>.

- \*1 Display of frequency and counter is common to all units.
- \*2 Display is changed according to the phase/wire system.

	Current	Voltage
Single-phase three-wire system	R-current, N-current, T-current	R-voltage, RT-voltage, T-voltage (P1-P0) (P1-P2) (P2-P0)
Three-phase three-wire system	R-current, S-current, T-current	RS-voltage, RT-voltage, TS-voltage (P1-P0) (P1-P2) (P2-P0)

【Outline for the Working of Option Mode Display】 only KW2G-H SD card type




By pressing <ITEM/Δ> during pressing <SET>, it shifts date or time.  
It doesn't shift the displayed items.

## 6.2 Display of each measurement value

### 【Unit change】

Press <MODE> to shift display of main unit (M) and expansion units (1 to 7).

Main unit **[M]** Lighting Expansion unit **[1]** **[2]** **[3]** to **[7]** Lighting




## 6.3 Display for power monitoring mode

### 6.3.1 Integrated electric power


•It displays the integrated electric power.

#### Example of 1P2W


Integrated electric power (1)[1.kWh/1.MWh] is displayed first and press <ITEM/Δ> to display integrated electric power (2)[2.kWh/2.MWh].



#### Example of 1P3W/3P3W




- Integrated electric power is measured and displayed from 0.00kWh to 9999.99MWh.
- The decimal point is changed automatically.



(After reaching the full scale (99999.9kWh), the value reverts to 0.00kWh but continues to measure.)

#### How to reset


•Hold down <SET> and press <MODE> makes integrated electric power clear.



**How to display with 9-digit**

Integrated electric power can be displayed with 9-digit.

- Press <MODE> during pressing <ITEM/Δ> at integrated electric power display (kWh/MWh), it changes to integrated electric power with 9-digit (kWh) and to integrated electric power with 3-digit under decimal point (kWh).




**6.3.2 Instantaneous electric power**


- It displays the instantaneous electric power.
- Press <ITEM/Δ> continuously to shift display, instantaneous active power(kW), instantaneous reactive power (kvar) and instantaneous apparent power (kVA).

**Example of 1P2W**

Instantaneous active power (1)[1.kW] is displayed first and press <ITEM/Δ> to display instantaneous active power (2)[2.kW].



**Example of 1P3W/3P3W**




- It determines plus or minus of instantaneous reactive power by the input measuring voltage and the input measuring current. When harmonics or a wave pattern is warped, it may not determine correctly.


### 6.3.3 Current

- It displays the current value.
- Press <ITEM/Δ> continuously to shift the display.
- \*When the display is different from the measured load system, set to the correct system at the setting mode. (Refer to 4.2.1 Phase/wire setting mode.)


**Example of 1P2W**



**Example of 1P3W**



**Example of 3P3W**



- When input current exceeds 150%F.S. at each range, 「 - - - - - 」 will be displayed.
- Current measurement parts


Eco-POWER METER measures the current as below.

System	Display	1.R-A / R-A	N-A / S-A	2.R-A / T-A
Single-phase two-wire system		R-current (1)	—	R-current (2)
Single-phase three-wire system		R-current	N-current	T-current
Three-phase three-wire system		R-current	S-current	T-current


### 6.3.4 Voltage

- It displays the voltage value.
- Press <ITEM/Δ> continuously to shift the display.
- \*When the display is different from the measured load system, set to the correct system at the setting mode. (Refer to 4.2.1 Phase/wire setting mode.)


**Example of 1P2W**



**Example of 1P3W**



**Example of 3P3W**



- When input voltage is under 5% of rating, it displays '0.0' and doesn't measure. ('Under 5%' means the value getting from this calculation 'rated voltage 200(400) x 0.05 x VT ratio'.)
- When input voltage exceeds 150%F.S. at each range, 「 - - - - - 」 will be displayed.
- Voltage measurement parts

Eco-POWER METER measures the voltage as below.


System \ Display	1.R-V / R-V / RS-V	RT-V	2R-V / T-V / TS-V
Single-phase two-wire	R(1)-voltage (Between P1 and P0) (Line voltage)	—	R(2)-voltage (Between P2 and P0) (Line voltage)
Single-phase three-wire	R-voltage (Phase voltage)	RT-voltage (Between P1 and P2) (Line voltage)	T-voltage (Phase voltage)
Three-phase three-wire	RS-voltage (Between P1 and P0) (Line voltage)	RT-voltage (Between P1 and P2) (Line voltage)	TS-voltage (Between P2 and P0) (Line voltage)

### 6.3.5 Electricity Charge


•It displays the standard electricity charge for the integrated electrical power.

#### Example of 1P2W

Electricity charge(1)[1.CHG] is displayed first and press <ITEM/Δ> to display electricity charge(2)[2.CHG].



#### Example of 1P3W/3P3W



•When the value exceeds '999999', 「- - - - -」 will be displayed.


### 6.3.6 Carbon dioxide conversion value

•It displays the standard conversion value for the integrated electrical power.

#### Example of 1P2W

CO<sub>2</sub> conversion value(1)[1.CO2] is displayed first and press <ITEM/Δ> to display CO<sub>2</sub> conversion value (2) [2.CO2].

CO<sub>2</sub> conversion value(1)      CO<sub>2</sub> conversion value(2)



#### Example of 1P3W/3P3W




•When the value exceeds '999999', 「- - - - -」 will be displayed.

### 6.3.7 Power factor


- It displays power factor of the load.

#### Example of 1P2W

Power factor (1)[1.PF] is displayed first and press <ITEM/Δ> to display power factor (2)[2.PF].



#### Example of 1P3W/3P3W



- It displays minus value when it detects the regeneration electric power. (Ex.: -1.00)

- How to calculate power factor

Eco-POWER METER displays power factor by calculating as below.

Single-phase two-wire	$PF = \frac{\text{Instantaneous electric power}}{\text{Voltage} \times \text{Current}}$
Single-phase three-wire	$PF = \frac{\text{Instantaneous electric power}}{2 \times \left( \text{Average of each phase V} \right) \times \left( \text{Average of each phase A} \right)}$
Three-phase three-wire	$PF = \frac{\text{Instantaneous electric power}}{\sqrt{3} \times \left( \text{Average of each phase V} \right) \times \left( \text{Average of each phase A} \right)}$

### 6.3.8 Frequency

- It displays the frequency of the voltage between P1 and P0.

#### Example




6.3.9 Hour meter


- It displays measured value using hour meter function such as ON-time.
- note) It doesn't display when software version is not supported.

Example of 1P2W

ON-time2(1) [1.ONh2] is displayed first and press <ITEM/Δ> to display ON-time2(2) [2.ONh2].




**Example of 1P3W/3P3W**



• After reaching the full scale (99999.9h), the value reverts to 0.0h but continues to measure.

**How to Reset ON-time2 ON-time1 OFF-time Maintenance time**

- Hold down **<SET>** and press **<MODE>** makes the displayed measured values clear.
- (When it can't calculate correctly, ratio of ON-time is '0' and it displays 「- - - - -」.)




Note: Hour meter function can be used only with main unit and one expansion unit.  
Expansion unit (Analog input) doesn't have the hour meter function.

6.3.10 Counter / Pulse input status


•It displays present count value (pulse input value) or pulse input status.

Example



How to Reset Count value


•At counter display, holding down <SET> and <MODE> continuously makes count value clear.



## 6.4 Display for option mode \*only KW2G-H SD card type

Press <ITEM/Δ> with counter display in power monitoring mode, and it displays [OPTION].

Press <SET> with [OPTION] display, it shifts to option mode.




### 6.4.1 Calendar/Timer

•It displays the present time.

•Press <SET> to change Year-month-day to time.

**Example**




### 6.4.2 Daily integrated electric power (kWh)

- It displays the daily integrated electric power. It can display a log data for the latest 8 days.
- Press <SET> to shift 1-day ago, 2-day ago, 3-day ago ... . Select day and it displays daily integrated power after 2 seconds.
- Press <ITEM/Δ> with holding down <SET> to shift 1-day later, 2-day later, 3-day later ... .
- Period of day is designated as below table. The displayed unit is 'kWh'.


Display	M D 0310		M D 0309		M D 0308	
	From	To	From	To	From	To
Measuring period	March 10 00:00:00	March 10 23:59:59	March 9 00:00:00	March 9 23:59:59	March 8 00:00:00	March 8 23:59:59

#### Example of 1P2W

Daily integrated electric power (1)




Daily integrated electric power (2)



**Example of 1P3W/3P3W**

Daily integrated electric power




**6.4.3 Hourly integrated electric power (kWh)**

- It displays hourly integrated electric power. It can display a log data for the latest 12 hours.
- Press <SET> to shift 1-hour ago, 2-hour ago, 3-hour ago ...
- Select day and it displays hourly integrated power after 2 seconds.
- Press <ITEM/Δ> with holding down <SET> to shift 1-hour later, 2-hour later, 3-hour later ...
- Period of hour is designated as below table. The displayed unit is 'kWh'.


Display	DH. M 1008.15		DH. M 1008.00		DH. M 1007.45	
	Measuring period	From 10 <sup>th</sup> 08:15:00	To 10 <sup>th</sup> 08:29:59	From 10 <sup>th</sup> 08:00:00	To 10 <sup>th</sup> 08:14:59	From 10 <sup>th</sup> 07:45:00

**Example of 1P2W**

Hourly integrated electric power (1)




Hourly integrated electric power (2)



Example of 1P3W/3P3W


Hourly integrated electric power



## 6.5 Other indication

### 6.5.1 Indication while communication

TX/RX indicator is blinking while Eco-POWER METER is under communication.




### 6.5.2 Error indication

Indication of number is blinking when main unit can't communicate with the expansion unit.

Numbers of error unit are blinking.


\*Turn off the power and turn on again when the error occurs.



## Chapter 7 Communication

### 7.1 Communication Procedures

Communication starts with command transmission from the host computer (hereafter Master) and ends with the response of Eco-POWER METER (hereafter Slave).



### 7.2 Communication timing

◆ The minimum access time from the master is 0.1 sec. (Minimum time for update the data)  
Eco-POWER METER may not response due to noise and so on, be sure to check that it receives the response from Eco-POWER METER.

◆ In order to improve the communication quality, we recommend to send the transmission again.

#### Communication timing of RS485

##### ◇Eco-POWER METER (Slave) side

When Eco-POWER METER (Slave) starts transmission to RS485 communication line, it is arranged so as to provide an idle status transmission period of about 1 to 99ms (setting available) before sending the response to ensure the synchronization on the receiving side. After sending the response, master can disconnect the transmitter from the communication line within transmission period 20ms.

##### ◇Master side (Cautions of setting a program)

At communication, keep the following conditions.


- 1) Set the program so that the master can disconnect the transmitter from the communication line within the transmission period of about 2ms after sending the command in preparation for reception of the response from Eco-POWER METER (Slave).
- 2) To avoid collision of transmissions between the master and Eco-POWER METER (Slave), send a next command after checking that the master received the response.

### 7.3 MEWTOCOL Communication


#### 7.3.1 Overview of MEWTOCOL-COM (RS485, USB)

◆Command and response functions

The computer sends commands (instructions) to Eco-POWER METER, and receives responses in return. This enables the computer and Eco-POWER METER to converse with each other, so that various kinds of information can be obtained and provided.



◆Command and response formats



◇Control codes

Name	Character	ASCII code	Explanation
Header	%	25H	Indicates the beginning of a message.
Command	#	23H	Indicates that the data comprises a command message.
Normal response	\$	24H	Indicates that the data comprises a normal response message.
Error response	!	21H	Indicates that the data comprises a response message when an error occurs.
Terminator	CR	0DH	Indicates the end of a message.

◇Destination and source AD (H), (L)

Two-digit decimal 01 to 99 (ASCII codes)

Command messages contain a station number for Eco-POWER METER that receives the message. When FF (ASCII code table) is used, however, the transmission is a global transmission (sent to all stations at once).

Note) When a global transmission is sent, no response to the command message is returned.

◇Block check code Bcc (H), (L)

Two-digit hexadecimal 00 to FF (ASCII codes)

These are codes (horizontal parity) that are used to detect errors in the transmitted data.

If "\*\*\*" is entered instead of 'Bcc', however, messages can be transmitted without the Bcc. In this case, the Bcc is included with the response

◇Error code Err (H), (L)


Two-digit hexadecimal 00 to FF (ASCII codes)

These indicate the content if an error occurs.

◆Bcc (Block Check Code)

-The Bcc is a code that carries out an error check using horizontal parity, to improve the reliability of the data being sent.

-The Bcc uses an exclusive OR from the header (%) to the final character of the text, and converts the 8-bit data into a 2-character ASCII code.



## 7.3.2 Data Register List (MEWTOCOL)

【M】:Main unit 【E】:Expansion unit Registers without 【 】 are common.

Data register	Name	Unit	Kind of data	Range	R/W
DT00000	Status	—	Unsigned 16bit	0: Normal 1: Error 0 to 7bit (communication error between main and expansion unit) 8bit (SD memory card writing error) 9bit (Battery shortage) A to Fbit (vacant)	R
DT00020	【M】CT type	Rated A(rms)	Unsigned 16bit	6 types: 5,50,100,250,400,600	R/W
DT00021	【E1】CT type	Rated A(rms)	Unsigned 16bit		
DT00022	【E2】CT type	Rated A(rms)	Unsigned 16bit		
DT00023	【E3】CT type	Rated A(rms)	Unsigned 16bit		
DT00024	【E4】CT type	Rated A(rms)	Unsigned 16bit		
DT00025	【E5】CT type	Rated A(rms)	Unsigned 16bit		
DT00026	【E6】CT type	Rated A(rms)	Unsigned 16bit		
DT00027	【E7】CT type	Rated A(rms)	Unsigned 16bit		
DT00030	【M】Cutoff current	0.10%	Unsigned 16bit	1 to 500	R/W
DT00031	【E1】Cutoff current	0.10%	Unsigned 16bit		
DT00032	【E2】Cutoff current	0.10%	Unsigned 16bit		
DT00033	【E3】Cutoff current	0.10%	Unsigned 16bit		
DT00034	【E4】Cutoff current	0.10%	Unsigned 16bit		
DT00035	【E5】Cutoff current	0.10%	Unsigned 16bit		
DT00036	【E6】Cutoff current	0.10%	Unsigned 16bit		
DT00037	【E7】Cutoff current	0.10%	Unsigned 16bit		
DT00040	【M】Primary side current value when CT 5A	1A	Unsigned 16bit	1 to 4000	R/W
DT00041	【E1】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00042	【E2】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00043	【E3】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00044	【E4】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00045	【E5】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00046	【E6】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00047	【E7】Primary side current value when CT 5A	1A	Unsigned 16bit		
DT00054	Rate (CHG)	0.01	Unsigned 16bit	0 to 9999	R/W
DT00055	Conversion factor (CO2)	0.001 kg-CO <sub>2</sub>	Unsigned 16bit	0 to 9999	R/W
DT00056	Simple measuring	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00057	Simple voltage	0.1V	Unsigned 32bit	0 to 99999	R/W
DT00058					
DT00059	Simple PF	0.01	Unsigned 16bit	0 to 100	R/W
DT00061	【M】Unit for Pulse output	—	Unsigned 32bit	1(0.001),10(0.01),100(0.1), 1000(1),10000(10),100000(100) 999 (Instantaneous electric power: Values of DT00064, 00065) 888 (Error alarm) 777 (Ratio for current alarm: Value of DT00069) 555 (Preset value for output: Values of DT00158,00159) 333 (Ratio and time for Stand-by alarm: Value of DT00077,00078) 111 (General-purpose output setting: Value of DT00095)	R/W
DT00062					

Data register	Name	Unit	Kind of data	Range	R/W
DT00064	【M】 Power alarm value (Instantaneous electric power)	0.01kW	Unsigned 32bit	0 to 999999	R/W
DT00065					
DT00066	VT ratio	0.01	Unsigned 16bit	100 to 9999	R/W
DT00068	Cutoff current	0.1%	Unsigned 16bit	1 to 500	R/W
DT00069	【M】 Ratio for current alarm	0.1%	Unsigned 16bit	10 to 1000	R/W
DT00070	Voltage range	—	Unsigned 16bit	2; 200V (Fixed)	R
DT00071	Calendar Monitor (Hour/Minute)	—	Unsigned 16bit	Higher word H: 00H to 23H Lower word M: 00H to 59H	R
DT00072	Calendar timer (Minute/Second)	—	Unsigned 16bit	Higher word M: 00H to 59H Lower word S: 00H to 59H	R/W
DT00073	Calendar timer (Date/Hour)	—	Unsigned 16bit	Higher word D: 01H to 31H Lower word H: 00H to 23H	R/W
DT00074	Calendar timer (Year/Month)	—	Unsigned 16bit	Higher word Y: 00H to 99H Lower word M: 01H to 12H	R/W
DT00075	Calendar timer (Day)	—	Unsigned 16bit	Higher word Day: 00H to 06H	R/W
DT00076	Log cycle setting	—	Unsigned 16bit	1(1),2(5),3(10),4(15),5(30),6(60)	R/W
DT00077	【M】 Ratio for stand-by current	0.1%	Unsigned 16bit	1 to 1000	R/W
DT00078	【M】 Time for stand-by alarm	1min.	Unsigned 16bit	0 to 9999	R/W
DT00079	【M】 General-purpose output judgement value	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00080	SRAM initialize	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00081	Saved file type 1	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00082	Saved file type 2	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00083	Saved file type 3	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT00086 Upper	【M】Shift average frequency	—	Unsigned 16bit	5 types: 0,2,4,8,16	R/W
DT00086 Lower	【E1】Shift average frequency				
DT00087 Upper	【E2】Shift average frequency	—	Unsigned 16bit		
DT00087 Lower	【E3】Shift average frequency				
DT00088 Upper	【E4】Shift average frequency	—	Unsigned 16bit		
DT00088 Lower	【E5】Shift average frequency				
DT00089 Upper	【E6】Shift average frequency	—	Unsigned 16bit		
DT00089 Lower	【E7】Shift average frequency				
DT00095	【M】General- purpose output type	—	Unsigned 16bit	0: Level output 1: Repeat cycle output 2: One-shot output	R/W
DT00096	【M】 Output ON-time	0.1sec.	Unsigned 16bit	1 to 100	R/W
DT00097	【M】 Output OFF-time	0.1sec.	Unsigned 16bit	1 to 100	R/W
DT00158	【M】 Preset value	—	Unsigned 32bit	0 to 999999	R/W
DT00159					
DT00160	【M】 Prescale value	0.001	Unsigned 32bit	1 to 100000	R/W
DT00161					

Data register	Name	Unit	Kind of data	Range	R/W
DT00162	<b>[M]</b> Max. counting speed	Hz	Unsigned 16bit	50000 or 30	R/W
DT00163	Auto-off time	min	Unsigned 16bit	0 to 99 (0:always on)	R/W
DT00198	<b>[M]</b> Pulse output width	ms	Unsigned 16bit	1 to 100	R/W

Data register	Name	Unit	Kind of data	Range	R/W
DT01000+N * 100	CH0 Preset value	—	Unsigned 32bit	0 to 999999	R/W
DT01000+N * 100+1					
DT01000+N * 100+2	CH1 Preset value	—	Unsigned 32bit	0 to 999999	R/W
DT01000+N * 100+3					
DT01000+N * 100+4	CH0 Prescale value	0.001	Unsigned 32bit	0 to 100000	R/W
DT01000+N * 100+5					
DT01000+N * 100+6	CH1 Prescale value	0.001	Unsigned 32bit	0 to 100000	R/W
DT01000+N * 100+7					
DT01000+N * 100+8	CH0 Max. counting speed	Hz	Unsigned 16bit	30, 50000	R/W
DT01000+N * 100+9	CH1 Max. counting speed	Hz	Unsigned 16bit	30, 0000	R/W
DT01000+N * 100+10	CH0 Scaling max.	—	Signed 32bit	-999999 to 999999	R/W
DT01000+N * 100+11					
DT01000+N * 100+12	CH1 Scaling max.	—	Signed 32bit	-999999 to 999999	R/W
DT01000+N * 100+13					
DT01000+N * 100+14	CH0 Scaling min.	—	Signed 32bit	-999999 to 999999	R/W
DT01000+N * 100+15					
DT01000+N * 100+16	CH1 Scaling min.	—	Signed 32bit	-999999 to 999999	R/W
DT01000+N * 100+17					
DT01000+N * 100+18	CH0 Point position	—	Unsigned 32bit	1(1), 10(0.1), 100(0.01), 1000(0.001), 10000(0.0001)	R/W
DT01000+N * 100+19					
DT01000+N * 100+20	CH1 Point position	—	Unsigned 32bit	1(1), 10(0.1), 100(0.01), 1000(0.001), 10000(0.0001)	R/W
DT01000+N * 100+21					
DT01000+N * 100+22	CH0 Input range	—	Unsigned 16bit	0: 0-5V, 01: 1-5V, 02: 0-20mA, 03: 4-20mA	R/W
DT01000+N * 100+23	CH1 Input range	—	Unsigned 16bit	0: 0-5V, 01: 1-5V, 02: 0-20mA, 03: 4-20mA	R/W
DT01000+N * 100+24	CH0 Shift average frequency	—	Unsigned 16bit	0,2,4,8,16	R/W
DT01000+N * 100+25	CH1 Shift average frequency	—	Unsigned 16bit	0,2,4,8,16	R/W
DT01000+N * 100+27	<b>[E]</b> Unit for Pulse output	—	Unsigned 32bit	1(0.001),10(0.01),100(0.1), 1000(1),10000(10), 100000(100) 999 (Instantaneous electric power)	R/W
DT01000+N * 100+28				888 (error alarm) 777(Ratio for current alarm) 555(Preset value for output) 333(Ratio and time for Stand-by alarm) 111(General-purpose output setting)	
DT01000+N * 100+29	<b>[E]</b> Pulse output width	—	Unsigned 16bit	1 to 100	R/W
DT01000+N * 100+30	<b>[E]</b> Power alarm value (Instantaneous electric power)	0.01kW	Unsigned 32bit	0 to 999999	R/W
DT01000+N * 100+31					
DT01000+N * 100+32	<b>[E]</b> Ratio for current alarm	0.1%	Unsigned 16bit	10 to 1000	R/W
DT01000+N * 100+33	<b>[E]</b> Ratio for stand-by current	0.1%	Unsigned 16bit	1 to 1000	R/W

N: Unit number      Main unit: N=0    Expansion unit: N=1 to 7

Data register	Name	Unit	Kind of data	Range	R/W
DT01000+N * 100+34	<b>[E]</b> Time for stand-by alarm	1min.	Unsigned 16bit	0 to 9999	R/W
DT01000+N * 100+35	<b>[E]</b> General-purpose output judgement value	—	Unsigned 16bit	0:OFF 1:ON	R/W
DT01000+N * 100+36	<b>[E]</b> General-purpose output type	—	Unsigned 16bit	0: Level output 1: Repeat cycle output 2: One-shot output	R/W
DT01000+N * 100+37	<b>[E]</b> Output ON-time	0.1sec.	Unsigned 16bit	1 to 100	R/W
DT01000+N * 100+38	<b>[E]</b> Ouput OFF-time	0.1sec.	Unsigned 16bit	1 to 100	R/W
DT02000+N * 100	<b>[E]</b> Current for time measurement 1 (1) *3	0.1%	Unsigned 16bit	0.1 to 100.0	R/W
DT02000+N * 100+1	<b>[E]</b> Current for time measurement 2 (1) *3	0.1%	Unsigned 16bit	0.1 to 100.0	R/W
DT02000+N * 100+2	<b>[E]</b> Current for time measurement 1 (2) *1 *3	0.1%	Unsigned 16bit	0.1 to 100.0	R/W
DT02000+N * 100+3	<b>[E]</b> Current for time measurement 2 (2) *1 *3	0.1%	Unsigned 16bit	0.1 to 100.0	R/W
DT02052	<b>[M]</b> Pulse input type (1)	—	Unsigned 16bit	0: Pulse count 1: Maintenace	R/W
DT02152	<b>[E1]</b> Pulse input type (1)	—	Unsigned 16bit	0: Pulse count 1: Maintenace	R/W
DT02153	<b>[E1]</b> Pulse input type (2) *1	—	Unsigned 16bit	0: Pulse count 1: Maintenace	R/W

## Measurement value

Data register	Name	Unit	Kind of data	Range	R/W
DT{(N+1) * 100}	Integrated active power ((1))	0.01kWh	Unsigned32bit	0 to 999999999	R/W
DT{(N+1) * 100}+1					
DT{(N+1) * 100}+11	Power factor ((1))	0.01	Signed 16bit	-100 to 100	R
DT00112	Frequency	0.1Hz	Unsigned 16bit	0 to 1000	R
DT{(N+1) * 100}+13	Power factor (2) *1	0.01	Signed 16bit	-100 to 100	R
DT{(N+1) * 100}+20	Integrated active Power ((1))	0.01kWh	Unsigned 32bit	0 to 999999999	R/W
DT{(N+1) * 100}+21					
DT{(N+1) * 100}+22	Integrated active power (2) *1	0.01kWh	Unsigned 32bit	0 to 999999999	R/W
DT{(N+1) * 100}+23					
DT{(N+1) * 100}+24	Voltage (R/RS) *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+25					
DT{(N+1) * 100}+26	Voltage (RT) *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+27					
DT{(N+1) * 100}+28	Voltage (T/TS) *1 *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+29					
DT{(N+1) * 100}+34	Current (R) *2	0.001A	Unsigned 32bit	0 to 60000000	R
DT{(N+1) * 100}+35					
DT{(N+1) * 100}+36	Current (N/S) *2	0.001A	Unsigned 32bit	0 to 60000000	R
DT{(N+1) * 100}+37					
DT{(N+1) * 100}+38	Current (T) *1 *2	0.001A	Unsigned 32bit	0 to 60000000	R
DT{(N+1) * 100}+39					
DT{(N+1) * 100}+40	Instantaneous active power((1))	0.1W	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+41					
DT{(N+1) * 100}+42	Instantaneous active power(2) *1	0.1W	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+43					
DT{(N+1) * 100}+50	Integrated active Power ((1))Wh	0.001kWh	Unsigned 32bit	0 to 999999999	R/W
DT{(N+1) * 100}+51					
DT{(N+1) * 100}+52	Integrated active power (2) Wh *1	0.001kWh	Unsigned 32bit	0 to 999999999	R/W
DT{(N+1) * 100}+53					
DT00154	<b>[M]</b> Pulse count value	—	Unsigned 32bit	0 to 999999	R/W
DT00155					

N: Unit number      Main unit: N=0    Expansion unit: N=1 to 7

Data register	Name	Unit	Kind of data	Range	R/W
DT{(N+1) * 100}+70	Voltage (R/RS) *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+71					
DT{(N+1) * 100}+72	Voltage (RT) *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+73					
DT{(N+1) * 100}+74	Voltage (T/TS) *1 *2	0.1V	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+75					
DT{(N+1) * 100}+76	Instantaneous active power ((1))	0.01 kW	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+77					
DT{(N+1) * 100}+78	Instantaneous reactive power ((1))	0.01 kvar	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+79					
DT{(N+1) * 100}+80	Instantaneous apparent power ((1))	0.01 kVA	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+81					
DT{(N+1) * 100}+82	Instantaneous active power (2) *1	0.01 kW	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+83					
DT{(N+1) * 100}+84	Instantaneous reactive power (2) *1	0.01 kvar	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+85					
DT{(N+1) * 100}+86	Instantaneous apparent power(2) *1	0.01 kVA	Unsigned 32bit	0 to 999999	R
DT{(N+1) * 100}+87					
DT{(N+1) * 100}+88	(CH0) Pulse input status	-	Unsigned 16bit	0: OFF, 1: ON	R
DT{(N+1) * 100}+89	CH1 Pulse input status	-	Unsigned 16bit	0: OFF, 1: ON	R
DT{(N+1) * 100}+90	CH0 Digital conversion value	-	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+91					
DT{(N+1) * 100}+92	CH1 Digital conversion value	-	Signed 32bit	-999999 to 999999	R
DT{(N+1) * 100}+93					
DT{(N+1) * 100}+94	CH0 Pulse counter	-	Unsigned 32bit	0 to 999999	R/W
DT{(N+1) * 100}+95					
DT{(N+1) * 100}+96	CH1 Pulse counter	-	Unsigned 32bit	0 to 999999	R/W
DT{(N+1) * 100}+97					
DT02000+N * 100+4	Actual work time (1) *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+5					
DT02000+N * 100+6	Actual work time (1) *3	0.1h	Unsigned 32bit	0 to 999999	R
DT02000+N * 100+7					
DT02000+N * 100+8	Actual work time (2) *1 *3	1min	Unsigned 32bit	0~5999994	R
DT02000+N * 100+9					
DT02000+N * 100+10	Actual work time (2) *1 *3	0.1h	Unsigned 32bit	0 to 999999	R
DT02000+N * 100+11					
DT02000+N * 100+12	OFF-time (1) *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+13					
DT02000+N * 100+14	OFF-time (1) *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+15					
DT02000+N * 100+16	OFF-time (2) *1 *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+17					
DT02000+N * 100+18	OFF-time (2) *1 *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+19					
DT02000+N * 100+20	ON-time1 (1) *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+21					
DT02000+N * 100+22	ON-time1 (1) *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+23					
DT02000+N * 100+24	ON-time1 (2) *1 *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+25					
DT02000+N * 100+26	ON-time1 (2) *1 *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+27					
DT02000+N * 100+28	ON-time2 (1) *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+29					

Data register	Name	Unit	Kind of data	Range	R/W
DT02000+N * 100+30	ON-time2 (1) *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+31					
DT02000+N * 100+32	ON-time2 (2) *1 *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+33					
DT02000+N * 100+34	ON-time2 (2) *1 *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+35					
DT02000+N * 100+36	Ratio of ON-time1 (1) *3	0.1%	Unsigned 16bit	0.0 to 100.0	R
DT02000+N * 100+37	Ratio of ON-time2 (1) *3	0.1%	Unsigned 16bit	0.0 to 100.0	R
DT02000+N * 100+38	Ratio of ON-time1 (2) *1 *3	0.1%	Unsigned 16bit	0.0 to 100.0	R
DT02000+N * 100+39	Ratio of ON-time2 (2) *1 *3	0.1%	Unsigned 16bit	0.0 to 100.0	R
DT02000+N * 100+40	Maintenace flag (1) *3	—	Unsigned 16bit	0: not available 1: available	R/W
DT02000+N * 100+41	Maintenace flag (2) *1 *3	—	Unsigned 16bit	0: not available 1: available	R/W
DT02000+N * 100+42	Maintenace time (1)*3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+43					
DT02000+N * 100+44	Maintenace time (1)*3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+45					
DT02000+N * 100+46	Maintenace time (2) *1 *3	1min	Unsigned 32bit	0 to 5999994	R
DT02000+N * 100+47					
DT02000+N * 100+48	Maintenace time (2) *1 *3	0.1h	Unsigned 32bit	0 to 999999	R/W
DT02000+N * 100+49					
DT02000+N * 100+50	Hour meter status (1) *3	—	Unsigned 16bit	0: OFF-time 1: ON-time1 2: ON-time2 3: Maintenace time	R
DT02000+N * 100+51	Hour meter status (2) *1 *3	—	Unsigned 16bit	0: OFF-time 1: ON-time1 2: ON-time2 3: Maintenace time	R

N: Unit number Main unit: N=0 Expansion unit: N=1 to 7

\*1 Data of 2<sup>nd</sup> circuit of single-phase two-wire system will be entered in name with \*1.

\*2 Data will be entered according to the setting system as below table in name with \*2.

•Current

Measuring point system	1.R-A / R-A	N-A / S-A	2.R-A / T-A
1P2W	DT00134 - 00135	—	DT00138 - 00139
1P3W		DT00136 - 00137	
3P3W			

•Voltage

Measuring point system	1.R-V / R-V / RS-V	RT-V	2R-V / T-V / TS-V
1P2W	DT00124 - 00125 DT00170 - 00171	—	DT00128 - 00129 DT00174 - 00175
1P3W		DT00126 - 00127 DT00172 - 00173	
3P3W			

\*3 Only for the main unit and one expansion unit. ('N' is 0 or 1.)

Note1) R: Read W: Write

2) Data register except specified is 0.

3) If each setting value is written by communication, it memories to internal EEPROM at the same time. Therefore, change setting frequently makes EEPROM's life short. Avoid to usage like this. However, general-purpose output judgement value is not written.

4) Write a data within the range when you write it.

5) Max reading point is 26 points (57-byte); max writing point is 23 points (55-byte).

6) When you use KW1M-R Eco-POWER METER (AKW1000) as a transmission device, DT00500 to 00502 can't be used. AKW1000 returns responses to the upper device.

### 7.3.3 Error Codes

#### ◇Basic procedure errors

Error code	Error name	Explanation
40H	Bcc error	• A Bcc error occurred in the command data.
41H	Format error	• A command message was sent that does not fit the transmission format.
42H	No support error	• A command was sent that is not supported.
43H	Procedure error	• Delimiter with multiple frames was sent. • The response shall be multiple frames.

#### ◇Application error

Error code	Error name	Explanation
60H	Parameter error	• The data code is not 'D'.
61H	Data error	• Word No. is specified without decimal. (0000F etc.) • The starting word No. is bigger than the ending word No. • Writing data has a code that is not hexadecimal.
62H	Registration error	• Too many registrations have been entered (more than 17). • 'MD' command was sent when some registration has been exist. • 'MG' command was sent when registration has not been entered.

#### ◇Self-diagnostic error

Error code	Error name	Explanation
45H	Operation error	• At 'WD' command, writing data is exceeded the range of data register.


### 7.3.4 Command

Eco-POWER METER has 5 kinds of commands.


Command name	Code	Explanation
Read data area	RD	Reads the contents of data area.
Write data to data area	WD	Writes data to a data area.
Register or Reset data monitored	MD	Registers the data to be monitored.
Monitoring start	MG	Monitors a registered data.
Read status	RT	Reads the specifications of Eco-POWER METER and error code if an error occurs.

#### ◆[RD]: Read data area (Reads the contents of data area.)


##### ◇Command



##### ◇Normal response (Read successful)




##### ◇Error response



#### ◆[WD]: Write data area (Writes data to a data area.)




##### ◇Command




##### ◇Normal response (Write successful)




◆[MD]: Register or Reset data monitored (Registers the data to be monitored.) \*Up to 16 points can be registered for one unit.



◆[MG]: Monitoring start (Monitors a registered data.)



◆[RT]: Read the status of Eco-POWER METER (Reads the specifications of Eco-POWER METER and error codes if an error occurs.)



\*With this unit, it responds "99" for Model code1, "40" for Model code2.

## 7.4 MODBUS (RTU) Communication

### 7.4.1 Overview of MODBUS (RTU)

◆8-bit binary data in command is transmitted as it is.

Data format	Start bit	: 1 bit
	Data bit	: 8 bits *7bits is not available.
	Parity	: No parity, Even parity, Odd parity Selectable
	Stop bit	: 1 bit (Fixed)
	Error detection	: CRC-16 (Cyclic Redundancy Check)
	Data interval	: 3.5 character transmission time or less

◆Message configuration

RTU mode is configured to start after idle time processing of more than 3.5 character transmissions and end after idle time processing of more than 3.5 character transmissions.

3.5 idle characters	Slave address	Function code	Data	Error check CRC-16	3.5 idle characters
	8-bit	8-bit	* * bits	16-bit	

Master judges the transmission complete after no command for 4-characters idle time and process the command.

\*Transmission speed and judgment time to complete transmission

Transmission speed (bps)	Judgment time to complete (ms)
38400	about 1.00
19200	about 2.00
9600	about 4.00
4800	about 8.00
2400	about 16.00

◇Slave address:

Slave address is an individual instrument number on the slave side and is set within the range 1 to 99 (01H to 63H). Master identifies slaves by the slave address of the requested message.

Slave informs master which slave is responding to master by placing its own address in the response message. Slave address 0 (00H, broadcast address) can identify all slaves connected. However slaves do not respond.

◇Function code: Function code is command code for the slave to undertake the following action types.

Function code	Contents
03(03H)	DT Read
06(06H)	DT1 word write
16(10H)	DT several data write

Function code is used to discern whether the response is normal (acknowledgement) or if any error (negative acknowledgement) has occurred when slave returns response message to master.

When acknowledgement is returned, slave simply returns original function code. When negative acknowledgement is returned, MSB of original function code is set as 1 for response.

For example, when the master sends request message setting 00H to function code by mistake, slave returns 80H by setting MSB to 1, because the former is an illegal function.

For negative acknowledgement, the exception codes below are set to data of response message and returned to master in order to inform it of what kind of error has occurred.

Exception code	Contents
1(01H)	Illegal Function (Non-existent function)
3(03H)	Illegal data value (Value out of the device numbers)

note1) Even if it commands to write (06H.10H) to non-existent data address, slave response with acknowledgement. However, it doesn't write.

note2) Even if it commands to write the value out of the setting range, slave response with acknowledgement. However, it doesn't write.

note3) The maximum number of reading slaves is 26 (57-byte), the maximum number of writing slaves is 23 (55-byte).

◇Data: Data depends on the function code.

A request message from the master side is composed of data item, number of data and setting data.

A response message from the slave side is composed of number of bytes, data and exception code in negative acknowledgement.

◇Error check: 16-bit data to detect communication errors. Refer to the next.

◇Acknowledgement response

When command is to write 1 point, same message of command is responded.

When command is to write several points, part of command message (6-byte) is responded.

◆Error check

After calculating CRC-16 (Cyclic Redundancy Check) from slave address to the end of data, the calculated 16-bit data is appended to the end of message in sequence from low order to high order.

<How to calculate CRC>

In CRC system, the information is divided by the polynomial series. The remainder is added to the end of the information and transmitted. The generation of polynomial series is as follows.

(Generation of polynomial series:  $X^{16} + X^{15} + X^2 + 1$ )

- 1) Initialize the CRC-16 data (assumed as X) (FFFFH).
- 2) Calculate exclusive OR (XOR) with the 1st data and X. This is assumed as X.
- 3) Shift X one bit to the right. This is assumed as X.
- 4) When a carry is generated as a result of the shift, XOR is calculated by X of 3) and the fixed value (A001H). This is assumed as X. If a carry is not generated, go to step 5).
- 5) Repeat steps 3) and 4) until shifting 8 times.
- 6) XOR is calculated with the next data and X. This is assumed as X.
- 7) Repeat steps 3) to 5).
- 8) Repeat steps 3) to 5) up to the last data.
- 9) Set X as CRC-16 to the end of message in sequence from low order to high order.

◆Message example

<1> Reading electricity rate (0036H) of address 1

•Command

3.5 idle characters	Slave address (01H)	Function code (03H)	Data item (0036H)	Number of data (0001H)	Error check CRC-16 (6404H)	3.5 idle characters
	1	1	2	2	2	←character number

•Response message from slave in normal status (When Rate=1000(10.00) [03E8H])

3.5 idle characters	Slave address (01H)	Function code (03H)	Number of response byte (02H)	Number of data (03E8H)	Error check CRC-16 (B8FAH)	3.5 idle characters
	1	1	1	2	2	←character number

<2> Setting electricity rate (0036H) of address 1 (When rate is set to 20.00(2000) [07D0H])

•Command

3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0036H)	Number of data (07D0H)	Error check CRC-16 (6A68H)	3.5 idle characters
	1	1	2	2	2	←character number


•Response message from slave in normal status

3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0036H)	Number of data (07D0H)	Error check CRC-16 (6A68H)	3.5 idle characters
	1	1	2	2	2	←character number


<3> Reset integrated electric power (0064H, 0065H: 2-word) of address 1

(When setting to 0 [0000, 0000H])

•Command



•Response message from slave in normal status




•A response message from the slave in exception (error) status

(When number of data has been mistaken.)

Function code MSB is set to 1 for the response message in exception (error) status (90H).


The exception code 03H (Value out of the device numbers) is returned as contents of error.

<Mistaken message example (Command)>



<Response message from slave to mistaken command

(Response message in exception (error) status)>



## 7.4.2 Data Register List (MODBUS communication)

【M】:Main unit 【E】:Expansion unit Registers without 【 】 are common.

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0000H (DT00000)	Status	—	Unsigned 16bit	0H(0): Normal 1H(1): Error 0 to 7bit (communication error between main and expansion unit) 8bit (SD memory card writing error) 9bit (Battery shortage) A to Fbit (vacant)	03H
0014H (DT00020)	【M】CT type	Rated A (rms)	Unsigned 16bit	6 types: 5H(5),32H(50),64H(100),FAH(250),190H(400), 258H(600)	03H/ 06H/10H
0015H (DT00021)	【E1】CT type	Rated A (rms)	Unsigned 16bit		
0016H (DT00022)	【E2】CT type	Rated A (rms)	Unsigned 16bit		
0017H (DT00023)	【E3】CT type	Rated A (rms)	Unsigned 16bit		
0018H (DT00024)	【E4】CT type	Rated A (rms)	Unsigned 16bit		
0019H (DT00025)	【E5】CT type	Rated A (rms)	Unsigned 16bit		
001AH (DT00026)	【E6】CT type	Rated A (rms)	Unsigned 16bit		
001BH (DT00027)	【E7】CT type	Rated A (rms)	Unsigned 16bit	1H to 1F4H (1 to 500)	03H/ 06H/10H
001EH (DT00030)	【M】Cutoff current	0.10%	Unsigned 16bit		
001FH (DT00031)	【E1】Cutoff current	0.10%	Unsigned 16bit		
0020H (DT00032)	【E2】Cutoff current	0.10%	Unsigned 16bit		
0021H (DT00033)	【E3】Cutoff current	0.10%	Unsigned 16bit		
0022H (DT00034)	【E4】Cutoff current	0.10%	Unsigned 16bit		
0023H (DT00035)	【E5】Cutoff current	0.10%	Unsigned 16bit		
0024H (DT00036)	【E6】Cutoff current	0.10%	Unsigned 16bit	1H to FA0H (1 to 4000)	03H/ 06H/10H
0025H (DT00037)	【E7】Cutoff current	0.10%	Unsigned 16bit		
0028H (DT00040)	【M】Primary side current value when CT 5A	1A	Unsigned 16bit		
0029H (DT00041)	【E1】Primary side current value when CT 5A	1A	Unsigned 16bit		
002AH (DT00042)	【E2】Primary side current value when CT 5A	1A	Unsigned 16bit		
002BH (DT00043)	【E3】Primary side current value when CT 5A	1A	Unsigned 16bit		
002CH (DT00044)	【E4】Primary side current value when CT 5A	1A	Unsigned 16bit		
002DH (DT00045)	【E5】Primary side current value when CT 5A	1A	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/ 06H/10H
002EH (DT00046)	【E6】Primary side current value when CT 5A	1A	Unsigned 16bit		
002FH (DT00047)	【E7】Primary side current value when CT 5A	1A	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/ 06H/10H
0036H (DT00054)	Rate (CHG)	0.01	Unsigned 16bit		
0037H (DT00055)	Conversion factor (CO <sub>2</sub> )	0.001 kg-CO <sub>2</sub>	Unsigned 16bit		

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0038H (DT00056)	Simple measuring	—	Unsigned 16bit	0H(0):OFF 1H(1):ON	03H/ 06H/10H
0039H<LSB> (DT00057)	Simple voltage	0.1V	Unsigned 32bit	0H to 1869FH (0 to 99999)	03H/ 06H/10H
003AH<MSB> (DT00058)					
003BH (DT00059)	Simple PF	0.01	Unsigned 16bit	0H to 64H (0 to 100)	03H/ 06H/10H
003DH<LSB> (DT00061)	【M】 Unit for Pulse output	—	Unsigned 32bit	1H(1)<0.001>, AH(10)<0.01>, 64H(100)<0.1>, 3E8H(1000)<1>, 2710H(10000)<10>, 186A0H(100000)<100>, 3E7H(999) < Instantaneous electric power: Values of 0040H,0041H> 378H(888)< Error alarm> 309H(777) < Ratio for current alarm: Value of 0045H> 22BH(555) < Preset value for output: Values of 009EH,009FH> 14DH(333) < Ratio and time for Stand-by alarm: Value of 004DH,004EH> 6FH(111) <General-purpose output type: Value off 005FH>	03H/ 06H/10H
003EH<MSB> (DT00062)					
0040H<LSB> (DT00064)	【M】 Power alarm value (Instantaneous electric power)	0.01kW	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
0041H<MSB> (DT00065)					
0042H (DT00066)	VT ratio	0.01	Unsigned 16bit	64H to 270FH (100 to 9999)	03H/ 06H/10H
0044H (DT00068)	Cutoff current	0.1%	Unsigned 16bit	1H to 1F4H (1 to 500)	03H/ 06H/10H
0045H (DT00069)	【M】 Ratio for current alarm	0.1%	Unsigned 16bit	1H to 3E8H (1 to 1000)	03H/ 06H/10H
0046H (DT00070)	Voltage range	—	Unsigned 16bit	2H(2); 200V <Fixed>	03H
0047H (DT00071)	Calendar Monitor (Hour/Minute)	—	Unsigned 16bit	H:00H to 23H, M:00H to 59H	03H
0048H (DT00072)	Calendar timer (Minute/Second)	—	Unsigned 16bit	M:00H to 59H, S:00H to 59H	03H/ 06H/10H
0049H (DT00073)	Calendar timer (Date/Hour)	—	Unsigned 16bit	D:01H to 31H, H:00H to 23H	03H/ 06H/10H
004AH (DT00074)	Calendar timer (Year/Month)	—	Unsigned 16bit	Y:00H to 99H, M:01H to 12H	03H/ 06H/10H
004BH (DT00075)	Calendar timer (Day)	—	Unsigned 16bit	Day:00H to 06H	03H/ 06H/10H
004CH (DT00076)	Log cycle setting	—	Unsigned 16bit	1H(1)<1>,2H(2)<5>, 3H(3)<10>,4H(4)<15>, 5H(5)<30>,6H(6)<60>	03H/ 06H/10H
004DH (DT00077)	【M】Ratio for stand-by current	0.1%	Unsigned 16bit	1H to 3E8H (1 to 1000)	03H/ 06H/10H
004EH (DT00078)	【M】Time for stand-by alarm	1min	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/ 06H/10H
004FH (DT00079)	【M】General-purpose output judgement value	—	Unsigned 16bit	0H(0):OFF 1H(1):ON	03H/ 06H/10H

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0050H (DT00080)	SRAM Initialize	—	Unsigned 16bit	0H(0)<OFF>,1H(1)<ON>	03H/ 06H/10H
0051H (DT00081)	Saved file type 1	—	Unsigned 16bit	0; OFF 1; ON	03H/ 06H/10H
0052H (DT00082)	Saved file type 2	—	Unsigned 16bit	0; OFF 1; ON	03H/ 06H/10H
0053H (DT00083)	Saved file type 3	—	Unsigned 16bit	0; OFF 1; ON	03H/ 06H/10H
0056H Upper (DT00086)	【M】Shift average frequency	—	Unsigned 16bit	5 types: 0H(0),2H(2),4H(4),8H(8), 10H(16)	03H/ 06H/10H
0056H Lower (DT00086)	【E1】Shift average frequency				
0057H Upper (DT00087)	【E2】Shift average frequency	—	Unsigned 16bit		
0057H Lower (DT00087)	【E3】Shift average frequency				
0058H Upper (DT00088)	【E4】Shift average frequency	—	Unsigned 16bit		
0058H Lower (DT00088)	【E5】Shift average frequency				
0059H Upper (DT00089)	【E6】Shift average frequency	—	Unsigned 16bit		
0059H Lower (DT00089)	【E7】Shift average frequency				
005FH (DT00095)	【M】General-purpose output type	—	Unsigned 16bit		
0060H (DT00096)	【M】Output ON-time	0.1sec.	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
0061H (DT00097)	【M】Output OFF-time	0.1sec.	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
009EH<LSB> (DT00158)	【M】Preset value	—	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
009FH<MSB> (DT00159)					
00A0H<LSB> (DT00160)	【M】Prescale value	0.001	Unsigned 32bit	1H to 186A0H (1 to 100000)	03H/ 06H/10H
00A1H<MSB> (DT00161)					
00A2H (DT00162)	【M】Max. counting speed	Hz	Unsigned 16bit	C350H (50000) , 1EH (30)	03H/ 06H/10H
00A3H (DT00163)	Auto-off time	min	Unsigned 16bit	0H to 63H (0 to 99)	03H/ 06H/10H
00C6H (DT00198)	【M】Pulse output width	—	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
044CH<LSB> (DT01100)	【E1】 CH0 Preset value	—	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
044DH<MSB> (DT01101)					
044EH<LSB> (DT01102)	【E1】 CH1 Preset value	—	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
044FH<MSB> (DT01103)					
0450H<LSB> (DT01104)	【E1】 CH0 Prescale value	0.001	Unsigned 32bit	0 to 100000	03H/ 06H/10H
0451H<MSB> (DT01105)					
0452H<LSB> (DT01106)	【E1】 CH1 Prescale value	0.001	Unsigned 32bit	0 to 100000	03H/ 06H/10H
0453H<MSB> (DT01107)					

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0454H (DT01108)	【E1】 CH0 Max. counting speed	Hz	Unsigned 16bit	C350H (50000) , 1EH (30)	03H/ 06H/10H
0455H (DT01109)	【E1】 CH1 Max. counting speed	Hz	Unsigned 16bit	C350H (50000) , 1EH (30)	03H/ 06H/10H
0456H<LSB> (DT01110)	【E1】 CH0 Scaling max.	—	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H/ 06H/10H
0457H<MSB> (DT01111)					
0458H<LSB> (DT01112)	【E1】 CH1 Scaling max.	—	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H/ 06H/10H
0459H<MSB> (DT01113)					
045AH<LSB> (DT01114)	【E1】 CH0 Scaling min.	—	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H/ 06H/10H
045BH<MSB> (DT01115)					
045CH<LSB> (DT01116)	【E1】 CH1 Scaling min.	—	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H/ 06H/10H
045DH<MSB> (DT01117)					
045EH<LSB> (DT01118)	【E1】 CH0 Point position	—	Unsigned 32bit	1H(1)<1>, AH(10)>0.1>, 64H(100)<0.01>, 3E8H(1000)<0.001>, 2710H(10000)<0.0001>	03H/ 06H/10H
045FH<MSB> (DT01119)					
0460H<LSB> (DT01120)	【E1】 CH1 point position	—	Unsigned 32bit	1H(1)<1>, AH(10)>0.1>, 64H(100)<0.01>, 3E8H(1000)<0.001>, 2710H(10000)<0.0001>	03H/ 06H/10H
0461H<MSB> (DT01121)					
0462H (DT01122)	【E1】 CH0 Input range	—	Unsigned 16bit	0H(0)<0-5V>, 1H(1)<1-5V>, 2H(2)<0-20mA>,3H(3)<4-20mA>	03H/ 06H/10H
0463H (DT01123)	【E1】 CH1 Input range	—	Unsigned 16bit	0H(0)<0-5V>, 1H(1)<1-5V>, 2H(2)<0-20mA>,3H(3)<4-20mA>	03H/ 06H/10H
0464H (DT01124)	【E1】 CH0 Shift average frequency	—	Unsigned 16bit	0H(0),2H(2),4H(4),8H(8), 10H(16)	03H/ 06H/10H
0465H (DT01125)	【E1】 CH1 Shift average frequency	—	Unsigned 16bit	0H(0),2H(2),4H(4),8H(8), 10H(16)	03H/ 06H/10H
0467H <LSB> (DT01127)	【E1】 Unit for Pulse output	—	Unsigned 32bit	1H(1)<0.001>, AH(10)<0.01>, 64H(100)<0.1>, 3E8H(1000)<1>, 2710H(10000)<10>, 186A0H(100000)<100>, 3E7H(999) <Instantaneous electric power> 378H(888)<Error alarm> 309H(777) < Ratio for current alarm> 22BH(555) < Preset value for output> 14DH(333) < Ratio and time for Stand-by alarm> 6FH(111) <General-purpose output setting>	03H/ 06H/10H
0468H <MSB> (DT01128)					
0469H (DT01129)	【E1】 Pulse output width	—	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
046AH<LSB> (DT01130)	【E1】 Power alarm value (Instantaneous electric power)	0.01kW	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
046BH<MSB> (DT01131)					
046CH (DT01132)	【E1】 Ratio for current alarm	0.1%	Unsigned 16bit	1H to 3E8H (1 to 1000)	03H/ 06H/10H
046DH (DT01133)	【E1】 Ratio for stand-by current	0.1%	Unsigned 16bit	1H to 3E8H (1 to 1000)	03H/ 06H/10H
046EH (DT01134)	【E1】 Time for stand-by alarm	1min	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/ 06H/10H

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
046FH (DT01135)	【E1】 General-purpose output judgement value	—	Unsigned 16bit	0H(0):OFF 1H(1):ON	03H/ 06H/10H
0470H (DT01136)	【E1】 General-purpose output type	—	Unsigned 16bit	0H(0): Level output 1H(1): Repeat cycle output 2H(2): One-shot output	03H/ 06H/10H
0471H (DT01137)	【E1】Output ON-time	0.1sec.	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
0472H (DT01138)	【E1】Output OFF-time	0.1sec.	Unsigned 16bit	1H to 64H (1 to 100)	03H/ 06H/10H
07D0H (DT2000)	【M】Current for time measurement 1 (1)	0.1%	Unsigned 16bit	1H to 3E8H (0.1 to 100.0)	03H/ 06H/10H
07D1H (DT2001)	【M】Current for time measuremen 2 (1)	0.1%	Unsigned 16bit	1H to 3E8H (0.1 to 100.0)	03H/ 06H/10H
07D2H (DT2002)	【M】Current for time measurement 1 (2) *1	0.1%	Unsigned 16bit	1H to 3E8H (0.1 to 100.0)	03H/ 06H/10H
07D3H (DT2003)	【M】Current for time measurement 2 (2) *1	0.1%	Unsigned 16bit	1H to 3E8H (0.1 to 100.0)	03H/ 06H/10H
0804H (DT2052)	【M】 Pulse input type (1)	—	Unsigned 16bit	0H: Pulse count 1H: Maintenace	03H/ 06H/10H
0868H (DT2152)	【E1】 Pulse input type (1)	—	Unsigned 16bit	0H: Pulse count 1H: Maintenace	03H/ 06H/10H
0869H (DT2153)	【E1】 Pulse input type (2) *1	—	Unsigned 16bit	0H: Pulse count 1H: Maintenace	03H/ 06H/10H

## Measurement value

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0064H<LSB> (DT00100)	【M】 Integrated active power ((1))	0.01kWh	Unsigned 32bit	0H to 3B9AC9FFH (0 to 999999999)	03H/ 06H/10H
0065H<MSB> (DT00101)					
006FH (DT00111)	【M】Power factor ((1))	0.01	Signed 16bit	FF9CH to 0064H (-100 to 100)	03H
0070H (DT00112)	Frequency	0.1Hz	Unsigned 16bit	0H to 3E8H (0 to 1000)	03H
0071H (DT00113)	【M】Power factor (2) *1	0.01	Signed 16bit	FF9CH to 0064H (-100 to 100)	03H
0078H<LSB> (DT00120)	【M】 Integrated active power ((1))	0.01kWh	Unsigned 32bit	0H to 3B9AC9FFH (0 to 999999999)	03H/ 06H/10H
0079H<MSB> (DT00121)					
007AH<LSB> (DT00122)	【M】 Integrated active power(2) *1	0.01kWh	Unsigned 32bit	0H to 3B9AC9FFH (0 to 999999999)	03H/ 06H/10H
007BH<MSB> (DT00123)					
007CH<LSB> (DT00124)	【M】 Voltage (R/RS)	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
007DH<MSB> (DT00125)					
007EH<LSB> (DT00126)	【M】 Voltage (RT)	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
007FH<MSB> (DT00127)					
0080H<LSB> (DT00128)	【M】 Voltage (T/TS) *1	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
0081H<MSB> (DT00129)					

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0086H<LSB> (DT00134)	【M】 Current (R)	0.001A	Unsigned 32bit	0H to 5B8D80H (0 to 6000000)	03H
0087H<MSB> (DT00135)					
0088H<LSB> (DT00136)	【M】 Current (N/S)	0.001A	Unsigned 32bit	0H to 5B8D80H (0 to 6000000)	03H
0089H<MSB> (DT00137)					
008AH<LSB> (DT00138)	【M】 Current (T) *1	0.001A	Unsigned 32bit	0H to 5B8D80H (0 to 6000000)	03H
008BH<MSB> (DT00139)					
008CH<LSB> (DT00140)	【M】 Instantaneous active power ((1))	0.0001 kW (0.1W)	Signed 32bit	FF676981H to 98967FH (-9999999 to 9999999)	03H
008DH<MSB> (DT00141)					
008EH<LSB> (DT00142)	【M】 Instantaneous active power(2) *1	0.0001 kW (0.1W)	Signed 32bit	FF676981H to 98967FH (-9999999 to 9999999)	03H
008FH<MSB> (DT00143)					
0096H<LSB> (DT00150)	【M】 Integrated active power Wh ((1))	0.001kWh	Unsigned 32bit	0H to 3B9AC9FFH (0 to 999999999)	03H/ 06H/10H
0097H<MSB> (DT00151)					
0098H<LSB> (DT00152)	【M】 Integrated active power Wh(2) *1	0.001kWh	Unsigned 32bit	0H to 3B9AC9FFH (0 to 999999999)	03H/ 06H/10H
0099H<MSB> (DT00153)					
009AH<LSB> (DT00154)	【M】 Pulse count value	—	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
009BH<MSB> (DT00155)					
00AAH<LSB> (DT00170)	【M】 Voltage (R/RS)	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00ABH<MSB> (DT00171)					
00ACH<LSB> (DT00172)	【M】 Voltage (ST)	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00ADH<MSB> (DT00173)					
00AEH<LSB> (DT00174)	【M】 Voltage (T/TS) *1	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00AFH<MSB> (DT00175)					
00B0H<LSB> (DT00176)	【M】 Instantaneous active power ((1))	0.01 kW	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00B1H<MSB> (DT00177)					
00B2H<LSB> (DT00178)	【M】 Instantaneous reactive power ((1))	0.01 kvar	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00B3H<MSB> (DT00179)					
00B4H<LSB> (DT00180)	【M】 Instantaneous apparent power ((1))	0.01 kVA	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00B5H<MSB> (DT00181)					
00B6H<LSB> (DT00182)	【M】 Instantaneous active power(2) *1	0.01 kW	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00B7H<MSB> (DT00183)					

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
00B8H<LSB> (DT00184)	【M】 Instantaneous reactive power(2) *1	0.01 kvar	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00B9H<MSB> (DT00185)					
00BAH<LSB> (DT00186)	【M】 Instantaneous apparent power(2) *1	0.01 kVA	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00BBH<MSB> (DT00187)					
00BCH (DT00188)	【M】Pulse input status	-	Unsigned 16bit	0: OFF, 1: ON	03H
0120H (DT00288)	【E1】 CH0 Pulse input status	-	Unsigned 16bit	0: OFF, 1: ON	03H
0121H (DT00289)	【E1】 CH1 Pulse input status	-	Unsigned 16bit	0: OFF, 1: ON	03H
00122H<LSB> (DT00290)	【E1】 CH0 Digital conversion value	-	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00123H<MSB> (DT00291)					
00124H<LSB> (DT00292)	【E1】 CH1 Digital conversion value	-	Signed 32bit	FF0BDC1H to F423FH (-999999 to 999999)	03H
00125H<MSB> (DT00293)					
00126H<LSB> (DT00294)	【E1】 CH0 Pulse counter	-	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
00127H<MSB> (DT00295)					
00128H<LSB> (DT00296)	【E1】 CH1 Pulse counter	-	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/ 06H/10H
00129H<MSB> (DT00297)					

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
07D4H<LSB> (DT2004)	【M】 Actual work time(1)	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07D5H<MSB> (DT2005)					
07D6H<LSB> (DT2006)	【M】 Actual work time(1)	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
07D7H<MSB> (DT2007)					
07D8H<LSB> (DT2008)	【M】 Actual work time(2)*1	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07D9H<MSB> (DT2009)					
07DAH<LSB> (DT2010)	【M】 Actual work time(2)*1	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
07DBH<MSB> (DT2011)					
07DCH<LSB> (DT2012)	【M】 OFF-time(1)	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07DDH<MSB> (DT2013)					
07DEH<LSB> (DT2014)	【M】 OFF-time(1)	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07DFH<MSB> (DT2015)					
07E0H<LSB> (DT2016)	【M】 OFF-time(2)*1	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07E1H<MSB> (DT2017)					
07E2H<LSB> (DT2018)	【M】 OFF-time(2)*1	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07E3H<MSB> (DT2019)					
07E4H<LSB> (DT2020)	【M】 ON-time1(1)	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07E5H<MSB> (DT2021)					
07E6H<LSB> (DT2022)	【M】 ON-time1(1)	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07E7H<MSB> (DT2023)					
07E8H<LSB> (DT2024)	【M】 ON-time1(2)*1	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07E9H<MSB> (DT2025)					
07EAH<LSB> (DT2026)	【M】 ON-time1(2)*1	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07EBH<MSB> (DT2027)					
07ECH<LSB> (DT2028)	【M】 ON-time2(1)	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07EDH<MSB> (DT2029)					

Data item (MEWTOCOL)	Name	Unit	Kind of data	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
07EEH<LSB> (DT2030)	【M】 ON-time2(1)	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07EFH<MSB> (DT2031)					
07F0H<LSB> (DT2032)	【M】 ON-time2(2)*1	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07F1H<MSB> (DT2033)					
07F2H<LSB> (DT2034)	【M】 ON-time2(2)*1	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07F3H<MSB> (DT2035)					
07F4H (DT2036)	【M】 Ratio of ON-time1(1)	0.1%	Unsigned 16bit	0H to 3E8H (0.0 to 100.0)	03H
07F5H (DT2037)	【M】 Ratio of ON-time2(1)	0.1%	Unsigned 16bit	0H to 3E8H (0.0 to 100.0)	03H
07F6H (DT2038)	【M】 Ratio of ON-time1(2)*1	0.1%	Unsigned 16bit	0H to 3E8H (0.0 to 100.0)	03H
07F7H (DT2039)	【M】 Ratio of ON-time2(2)*1	0.1%	Unsigned 16bit	0H to 3E8H (0.0 to 100.0)	03H
07F8H (DT2040)	【M】 Maintenance flag (1)	—	Unsigned 16bit	0H: not available 1H: available	03H/ 06H/10H
07F9H (DT2041)	【M】 Maintenance flag (2)*1	—	Unsigned 16bit	0H: not available 1H: available	03H/ 06H/10H
07FAH<LSB> (DT2042)	【M】 Maintenance time(1)	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07FBH<MSB> (DT2043)					
07FCH<LSB> (DT2044)	【M】 Maintenance time(1)	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
07FDH<MSB> (DT2045)					
07FEH<LSB> (DT2046)	【M】 Maintenance time(2) *1	1min	Unsigned 32bit	0H to 5B8D7AH (0 to 5999994)	03H
07FFH<MSB> (DT2047)					
0800H<LSB> (DT2048)	【M】 Maintenance time(2) *1	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/10H
0801H<MSB> (DT2049)					
0802H (DT2050)	【M】 Hour meter status (1)	—	Unsigned 16bit	0H: OFF-time 1H: ON-time1 2H: ON-time2 3H: Maintenance time	03H
0803H (DT2051)	【M】 Hour meter status (2) *1	—	Unsigned 16bit	0H: OFF-time 1H: ON-time1 2H: ON-time2 3H: Maintenance time	03H

<LSB>: Least Significant Byte

<MSB>: Most Significant Byte

Data of 2<sup>nd</sup> circuit of single-phase two-wire system will be entered in name with \*1.

Refer to 'Data Register List (MEWTOCOL)' about measuring data of expansion unit.

note 1) 03H: Read 06H/10H: Write

2) Data register except specified is "0".

3) If each setting value is wrote by communication, it memories to internal EEP-ROM at the same time. Therefore, change setting frequently makes EEP-ROM's life short. Avoid to usage like this. However, general-purpose output judgement value is not written.

4) Write a data within the range when you write it.

5) When you use KW1M-R Eco-POWER METER (AKW1000) as a transmission device, 01F4H to 01F6H can't be used. AKW1000 returns responses to the upper device.

## 7.5 Status

It shows the status with bit.

Ex.) Battery shortage (0200(H))

Number (H)	0				2				0				0			
bit number	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
bit value	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0

bit value 0: normal    bit value 1: error

Bit number	Name	Contents
0	Communication error between main and expansion unit	It can't communicate between main unit and expansion unit correctly.  0: main unit 1: expansion unit 1    2: expansion unit 2 3: expansion unit 3    4: expansion unit 4 5: expansion unit 5    6: expansion unit 6 7: expansion unit 7
1		
2		
3		
4		
5		
6		
7		
8	SD memory card writing error	It can't write data to SD memory card.
9	Battery shortage	There are some errors with battery or battery capacity is shortage.
A to F	Vacant	—

\* When communication error occurs, turn off the power and turn on again.


## Chapter 8 How to update the firmware

### 8.1 Prepare Eco-POWER METER to update

- 1) Power off KW2G Eco-POWER METER main unit (including expansion unit).
- 2) With pressing 3 keys of <MODE>, <SET> and <ITEM/▲>, power on KW2G Eco-POWER METER.


After unit numbers and [PROG] are displayed on the upper line, release the keys.  
Unit number [M] and [PROG] on the upper line and current version [xx.xx] are displayed.

This is ready to update the firmware of Eco-POWER METER.




### 8.2 Update the firmware using KW Version Upgrade Tool

- 1) Start 'KW Version Upgrade Tool'.  
Click [Version] and it displays the current version of connected units.  
Check the boxes of unit number to update firmware.




When timed out error is occurred, check the below.


- Is Eco-POWER METER ready to update?
- Is USB cable connected correctly?
- Are communication port and timeout value conformed?




- 2) Click [Refer] and it opens the window to select firmware.  
Select file to update 'kw2gverxxxx\_verup.kw2' and click [Open].  
\*You can download from our website the latest firmware.



- 3) When selected file name is displayed, click [Update].



The firmware in Eco-POWER METER is same or newer version of selected firmware, the window to skip or not is appeared. When you don't update the firmware, click [Yes] to finish it.




When you have used KW Version Upgrade Tool before, it displays the last updated firmware. If the firmware was moved, the error window will be appeared. Select firmware again and update it.




4) When it starts updating, the indicator is appeared and it updates to the selected firmware.


[Display of Eco-POWER METER]



Do not turn off Eco-POWER METER.




5) When it completes updating the firmware, the complete window will be appeared. Click [OK].



- 6) Cells of unit that its firmware is updated correctly are white.  
 You can confirm with the display of Eco-POWER METER.  
 After upgrading, [ROMV] is displayed on the upper line and version is displayed on the lower line.

[Display of Eco-POWER METER]




After completing download, cell of unit that its firmware is not updated, is yellow and cell of unit that updating is failure is red.


On the display of Eco-POWER METER, [PROG] is displayed on the upper line and [ - - - ] is displayed on the lower line.

Check and confirm the wiring of Eco-POWER METER and so on and update again.

[Display of Eco-POWER METER]



When click [Update] to update unit that update failed again, the below window might be appeared.  
In this case, click [No] and update it.



- 7) Click [Exit] to close KW Version Upgrade Tool.  
Power off KW2G Eco-POWER METER and turn on again.  
After that you can use KW2G Eco-POWER METER.

## Chapter 9 Specifications

### 9.1 Main unit, Expansion unit (power measurement)

Phase and wire system	Single-phase two-wire system, Single-phase three-wire system, (common) Three-phase three-wire system	
Rated operating voltage	100-240V AC (Add to main unit)	
Rated frequency	50/60Hz common	
Rated power consumption	Main unit: 6VA (15VA max.) Expansion unit (Power measurement): 0.5VA/unit (240VAC at 25°C)	
Inrush current	Max. 30A (240VAC at 25°C)	
Allowable operating voltage range	85 to 264V AC (85 to 110% of rated operating voltage)	
Allowable momentary power-off time	10ms	
Ambient temperature	-10 to +50°C (-25 to +70°C at storage)	
Ambient humidity	30 to 85%RH (at 20°C non-condensing)	
Breakdown voltage(initial)	Between the isolated circuits: 1500V/1min Detective current: 10mA or less	A)Outer edge (enclosure) – All terminals B)Between Insulated circuit [Main unit] •USB terminal – All other terminals •RS485 – All other terminals •Pulse output terminals – All other terminals *Voltage input terminals are not insulated CT input terminals. *Voltage input terminals are not insulated pulse input terminals.
Insulation resistance(initial)	Between the isolated circuits: 100MΩ or more (measured at 500V DC)	Same as the breakdown voltage.
Vibration resistance	16.7Hz total amplitude (double amplitude):4mm (1h on 3 axes) *1	
Shock resistance	DIN rail mounting: Min. 294m/s <sup>2</sup> (5 times on 3 axes)	
Display method	LCD with backlight (green) Upper: 5-digit (7-segment 1-digit+ 16-segment 4digit) letters' H::6.0mm Lower: 6-digit (7-segment) letter' H:6.5mm	
Connectable unit number	Max. 7 (for one main unit)	
Power failure Memory method	EEPROM (more than 100,000 overwrite) Memory items: Setting value, Measuring value	
Size	Main unit:50×95×65 mm, Expansion unit:25×95×65 mm	
Mounting method	DIN rail mounting	
Weight	KW2G Main unit: 180g KW2G-H Main unit SD card type: 185g (without battery) Expansion unit (Power measurement): 80g	

\*1 Based on JIS C1216 5.2.3(5) and 5.2.3(6)

\*2 Between each channel of expansion unit (Pulse input/ Analog input) is not insulated.

## 9.2 Measurement


### ● Electric power input (Main unit, Expansion unit (power measurement))

Phase and wire system		Single-phase two-wire system Single-phase three-wire system Three-phase three-wire system	(common)
Measurement circuit	Main unit	1-circuit (When measuring 1P2W: 2-circuit)	(1-power source system)
	Expansion unit	1-circuit (When measuring 1P2W: 2-circuit)	
Max. measurement circuit		8-circuit (When measuring 1P2W: 16-circuit) (One main unit +7 expansion units)	
Input measurement Voltage	Rating	Single-phase two-wire system: 100-240V AC (Line voltage) Single-phase three-wire system: 100-120V AC (Phase voltage) Three-phase three-wire system: 100-240V AC (Line voltage)	
	Allowable measurement voltage	85 to 110% of rated input voltage Single-phase two-wire system: 85-264V AC (Line voltage) Single-phase three-wire system: 85-132V AC (Phase voltage) Three-phase three-wire system: 85-264V AC (Line voltage)	
	VT ratio	1.00 to 99.99 (Set with setting mode) <b>*Voltage transformer (VT) is required when you measure a load with voltage over 240VAC (Allowable measurement voltage).</b> <b>*Secondary voltage rating of VT is 110V.</b>	
Input measurement Current	Rating	<Using the dedicated CT> •5A/50A/100A/250A/400A/600A (Select with setting mode) <Using a commercial CT with the secondary side current 5A> •1 to 4000A (Set with setting mode) <b>*Use CT with secondary side current of 5A when measure 600A or more.</b>	
	Allowable measurement current	120% of rated input voltage	
Special Functions	Cut-off current	0.1 to 50.0%F.S. (Set with setting mode)	
	Cut-off voltage	Below 5% of rating voltage (Rating voltage x 0.05 x VT ratio) (Fixed)	
Accuracy (without error in CT and VT)	· Instantaneous electric power · Integrated electric power · Electricity charge · Conversion value	$\pm(2.0\% \text{ F.S.} + 1 \text{ digit})$ (at 20°C, rated input, rated frequency, power factor 1) <b>*Accuracy coverage: 10 to 100% of CT</b>	
	Current	$\pm(1.0\% \text{ F.S.} + 1 \text{ digit})$ (at 20°C, rated input, rated frequency, power factor 1) <b>*Accuracy coverage: 10 to 100% of rated current</b>	
	Voltage	$\pm(1.0\% \text{ F.S.} + 1 \text{ digit})$ (at 20°C, rated input, rated frequency, power factor 1)	
	Temperature characteristics	$\pm(1.0\% \text{ F.S.} + 1 \text{ digit})$ (Range of -10 to 50°C, rated input, power factor 1)	
	Hour meter	$\pm(0.01\% + 1 \text{ digit})$ (at 20°C)	
	Frequency characteristics	$\pm(1.0\% \text{ F.S.} + 1 \text{ digit})$ (Frequency change $\pm 5\%$ based on rated frequency for rated input, power factor 1)	
Data update cycle		100ms	

●Pulse input \*only Main unit

Input channel	1 channel	
Input method	Contact / non-voltage a contact or open-collector	
Insulation method	Non-isolated with internal circuit	
Input mode	Addition (Fixed)	
Max. counting speed	50kHz/30Hz (Select with setting mode)	
Pulse input	Min. input signal width: 0.01ms(When 50kHz selected)/ 16.7ms(When 30Hz selected) ON:OFF ratio = 1:1	
Input signal	Contact / No contact (open collector) • Impedance when shorted: Max. 1k $\Omega$ • Residual voltage when shorted: Max. 2V • Impedance when open: Min. 100k $\Omega$	
Output mode (Main unit)	HOLD (Over count)	
Prescale	Decimal point	under 3-digit
	Range	0.001 to 100.000 (Set with setting mode)

<Circuit diagram>




### 9.3 Output Specifications

●Pulse output (Transistor output) \*only Main unit

Number of output point	1 point	
Insulation method	Optical coupler	
Output type	Open collector	
Output capacity	100mA 30V DC	
Pulse width (when pulse output with integrated electric power selected.)	1 to 100ms (Selectable with setting mode) *1	
ON state voltage drop	1.5V or less	
OFF state leakage current	100 $\mu$ A or less	
Pulse output unit	0.001/0.01/0.1/1/10/100kWh/Power alarm(AL-P)/ Current alarm(AL-C) /Stand-by alarm (AL-S) /Counter(Cnt) / General-purpose output (OUT) / Error alarm (Error) (Selectable with setting mode)	
General-purpose output *2	Level output / Repeat cycle output / One-shot output (Selectable with setting mode)	
Output ON-time, Output OFF-time	0.1 to 10.0s (Selectable with setting mode)	


<Circuit diagram>



ZD:Zener diode for surge voltage absorb  
Tr: NPN transistor

Note) Output circuit has no protection circuit for short.

\*1 The max. pulse output cycle is 25ms in order to work correctly and output 1 to 10ms pulse output. Therefore the pulse output unit should be set as that it output 40 pulses or less in 1 second.



\*2 In order to use the general-purpose output, it is necessary to set the output status ON or OFF via communications. In addition it doesn't work with the on-time and off-time set to under 0.1s.

## 9.4 Communication Specifications

< RS485 >

Interface	Conforming to RS485	
Protocol	MEWTOCOL/MODBUS(RTU) (selectable with setting mode)	
Isolation status	Isolated with the internal circuit	
Number of connected units	99 (max.) *2 *3	
Transmission distance	1200m (max.) *1	
Transmission speed	115200/57600/38400/19200/9600/4800/2400bps (selectable with setting mode)	
Transmission Format	Data length	8bit/7bit (selectable with setting mode) *4
	Parity	Not available / Odd number / Even number (selectable with setting mode)
	Stop bit	1bit /2bit (selectable with setting mode)
Communication method	Half-duplex	
Synchronous system	Synchronous communication method	
Ending resistance	approx. 120 Ω (built-in)	


\*1 Please check with the actual devices when some commercial devices with RS485 interface are connected. The number of connected devices, transmission distance, and transmission speed may be different according to using transmission line.

\*2 For RS485 converter on the computer side, we recommend SI-35 and SI-35USB (from LINE EYE Co.,Ltd.).

\*3 When using SI-35, SI-35USB or PLC from our company (which can be connected up to 99 units), up to 99 Eco-POWER METER can be connected. In case using this system with the other devices, up to 31 Eco-POWER METER can be connected.

\*4 With MODBUS (RTU) protocol, it works only with 8bit.

\*5 伝送速度及び接続台数により伝送速度が下記の通り制限されます。  
38400bps 以下の速度では、最大 1200m、99 台になります。



< USB >

Electric specification	Conform to USB2.0 standard
Connector shape	USB series MiniB
Insulation method	Insulated to internal circuit
Transmission speed	12Mbps(Full-Speed)
Transmission function	Computer link (MEWTOCOL)

\*Install the dedicated USB driver before using USB port.

(The USB driver is downloaded with KW Monitor (our free software) Download from our website. Customers' registration is required to download.)

\*Only MEWTOCOL is supported by USB communication.

## 9.5 Main Unit Memory Specifications (only KW2G-H SD card type: AKW2020G)

### Logging Function

File type 1 (Instantaneous value) *1	Save cycle	15 minutes (every day 00:00:00) (fixed)
	Saved data	(Instantaneous value) Integrated electric power(1), Integrated electric power(2), Instantaneous electric power: active(1), active(2), reactive(1), reactive(2), apparent(1), apparent(2) R(1)-current, N/S-current, R(2)/T-current, R(1)(R/RS)-voltage, RT-voltage, R(2)(T/TS)-voltage, Power factor(1), Power factor(2), Frequency, Count value CH0 digital conversion value, CH1 digital conversion value, CH0 pulse count value, CH1 pulse count value
	Saved data amount	96 records for 1 file (Max. 8 days)
File type 2 (Difference value) *1	Save cycle	15 minutes (every day 00:00:00) (fixed)
	Saved data	(Difference value) Integrated electric power(1), Integrated electric power(2), Count value CH0 pulse count value, CH1 pulse count value
	Saved data amount	96 records for 1 file (Max. 8 days)
File type 3 (Detail instantaneous value) *1	Save cycle	Selectable from 1min, 5min, 10min, 15min, 30min, 60min. (Saved timing) 1min selected: Just at every minute 5min selected: 00,05,10,15,20,25,30min... of every hour 10min selected: 00,10,20,30,40,50min of every hour 15min selected: 00,15,30,45min of every hour 60min selected: Just at every hour
	Saved data	(Instantaneous value) Integrated electric power(1), Integrated electric power(2), Instantaneous electric power: active(1), active(2), reactive(1), reactive(2), apparent(1), apparent(2) R(1)-current, N/S-current, R(2)/T-current, R(1)(R/RS)-voltage, RT-voltage, R(2)(T/TS)-voltage, Power factor(1), Power factor(2), Frequency, Count value CH0 digital conversion value, CH1 digital conversion value, CH0 pulse count value, CH1 pulse count value
	Saved data amount	Max. 720 records about 12-hours (In case of 1 min of save cycle)
Display		Daily integrated electric power (Latest 8 days) Hourly integrated electric power (Latest 12 hours)
Calendar timer		Time accuracy (Monthly accuracy) ±30 seconds (at 25°C)
Backup contents by battery		Time measurement and log data storage
Battery life	*2	About 2 years (at 25°C) (when no power)

\*1 You can select if the data of file type 1, 2 and 3 is written to SD memory card with setting mode. It makes files for each unit.

'Integrated electric power' is logged with the unit of 0.01kWh. It doesn't log it with the unit of 0.001kWh.

\*2 when battery power is reduced, 'BATT' is blinking. Replace battery according to the procedures. Battery life will be short if using this under high-temperature.

## 9.6 External Memory Specifications (only KW2G-H SD card type: AKW2020G)

### ●SD memory card slot

Support media	SD memory card	*1
Applied format standard	SD and SDHC standard	*2

\*1 Confirmed manufacturer: Panasonic Co. 2GB, 4GB class 4 or more

\*2 UHS standard is not supported.

When using SD memory card that is not confirmed, it has a possibility that it can't write the logging data.

#### <Care for handling SD memory card>

Be sure to format before using. In order to format SD memory card, use Panasonic format software. You can download from Panasonic website.

File system of SD memory card formatted by PC's software is not supported SD memory card standard generally.

In the following cases, there is a possibility to lose the saved data in SD memory card. Please understand us beforehand; we don't have any responsibility for losing data or the other directly or indirectly failures.

- 1) When user or someone else do mistake to handle with SD memory card
- 2) When static electricity and the electrical noise influence the SD memory card
- 3) When SD memory card is removed or power supply of main unit turns off during the access LED is blinking on the main unit

\*We recommend that you always save an important data in other media to backup.

We recommend using this Eco-POWER METER with inserting SD memory card.

If it is not inserted, log data for 8 days will be saved in the internal memory.

We recommend moving or deleting logging data in the folder created by KW2G-H regularly (every 1-month). When inserting SD memory card, delete the logging data in the folder created by KW2G-H.

When you turn off the Eco-POWER METER, remove the SD memory card first. If not, it might damage the Eco-POWER METER and SD memory card.

When you turn on the power again, it may access to SD memory card for 25 minutes according to the log data in the internal memory.

## 9.7 Self-diagnostic function

If an error occurs, the following indication will be given.

Indicator	Meaning	Output status	To recover
Err0	CPU error	OFF	Turn the power off and then on again.
Err1	Memory error*		EEPROM life ended. Replace the unit.

\*Includes the possibility that the EEPROM's life has expired.

## 9.8 Power Failure Memory

Eco-POWER METER memories integrated electric power and working status to internal EEPROM until when power supply is off. (Power failure guarantee)

And every time to change each setting, each setting value is memorized to internal EEPROM at the same time. Therefore, change setting frequently makes EEPROM's life short. Avoid to usage like this.

\*Especially be careful if you set by communication.

## 9.9 Applicable standard

Safety standard	EN61010-1		
EMC	EMI EN61326-1	Radiation interference field strength Noise terminal voltage	CISPR11 class A CISPR11 class A
	EMS EN61326-1	Static discharge immunity RF electromagnetic field immunity EFT/B immunity Surge immunity Conductivity noise immunity Power frequency magnetic field immunity Voltage dip / Instantaneous stop / Voltage fluctuation immunity	EN61000-4-2 EN61000-4-3 EN61000-4-4 EN61000-4-5 EN61000-4-6 EN61000-4-8 EN61000-4-11

## 9.10 Dedicated Current Transformer Specifications

### ● Clamp-on type

Model No	AKW4801C	AKW4802C	AKW4803C	AKW4804C	AKW4808C
Primary side rated current	5A / 50A	100A	250A	400A	600A
Secondary side rated Current	1.67mA / 16.7mA	33.3mA	125mA	200mA	200mA
Transform ratio	3000:1	3000:1	2000:1	2000:1	3000:1
Ratio error	±2.0% F.S.				
Hole Dia (mm)	φ 10	φ 16	φ 24	φ 36	φ 36
Breakdown voltage (initial)	AC1000V/1min (Between through hole and output lead wire)		AC2000V/1min (Between through hole and output lead wire)		
Insulation resistance (initial)	Min. 100MΩ (at DC500V) (Between through hole and output lead wire)				
Vibration resistance	Functional	10 to 55Hz (1 cycle/ minute) single amplitude of 0.15mm (10 min. on X,Y and Z axes)			
	Destructive	10 to 55Hz (1 cycle/ minute) single amplitude of 0.375mm (1 hrs. on X,Y and Z axes)			
Shock resistance	Functional	Min. 98m/s <sup>2</sup> (4 times on X,Y and Z axes)			
	Destructive	Min. 294m/ s <sup>2</sup> (5 times on X,Y and Z axes)			
Output protection level	±7.5V with clamp element		±3.0V with clamp element		
Permissible clamping frequency	Approx. 100 times				
Ambient temperature	-10 to +50°C (without frost and non-condensing)				
Storage temperature	-20 to +60°C (without frost and non-condensing)				
Ambient humidity	30 to 85%RH (at 20°C non-condensing)				
Weight (with relay cable)	Approx. 60g	Approx. 90g	Approx. 200g	Approx. 295g	Approx. 450g

### ● Through type

Model No	AKW4506C	AKW4507C	AKW4508C
Primary side rated current	50A / 100A	250A / 400A	600A
Secondary side rated Current	16.7mA / 33.3mA	125mA / 200mA	200mA
Transform ratio	3000:1	2000:1	3000:1
Ratio error	±1.0%F.S.		
Hole Dia (mm)	φ 17	φ 36	
Breakdown voltage (initial)	AC1000V/1min (Between through hole and output lead wire)	AC2000V/1min (Between through hole and output lead wire)	
Insulation resistance (initial)	Min. 100MΩ (at DC500V) (Between through hole and output lead wire)		
Vibration resistance	Functional	10 to 55Hz (1 cycle/ minute) single amplitude of 0.15mm (10 min. on X,Y and Z axes)	
	Destructive	10 to 55Hz (1 cycle/ minute) single amplitude of 0.375mm (1 hrs. on X,Y and Z axes)	
Shock resistance	Functional	Min. 98m/s <sup>2</sup> (4 times on X,Y and Z axes)	
	Destructive	Min. 294m/ s <sup>2</sup> (5 times on X,Y and Z axes)	
Output protection level	±7.5V with clamp element	±3.0V with clamp element	
Ambient temperature	-10 to +50°C (without frost and non-condensing)		
Storage temperature	-20 to +60°C (without frost and non-condensing)		
Ambient humidity	30 to 85%RH (at 20°C non-condensing)		
Weight (with relay cable)	Approx. 70g	Approx. 200g	Approx. 215g


**Note) Dedicated current transformers (CT) are dedicated for low voltage under 440V. They can not be used for high voltage circuit. In case measuring high voltage circuit, make a 2-step construction by combination of a commercial CT of secondary side current 5A for high voltage and the dedicated CT for 5A.**

## Chapter 10 Mounting


### 10.1 Dimensions

(Unit: mm)  
(tolerance:  $\pm 1.0$ )


#### 10.1.1 KW2G Main unit




10.1.2 KW2G-H SD card type Main unit



10.1.3 Expansion unit (power measurement)




◆ DIN rail mounting




Be sure to fix by hooks when expanding.

◆ Panel cutout




10.1.4 Dedicated CT


◆ For 5A/50A (AKW4801C)




◆ For 100A (AKW4802C)




◆ For 250A (AKW4803C)




◆ For 400A (AKW4804C)




◆ For 600A (AKW4808C)




◆ For 50A/100A (AKW4506C)



◆ For 250A/400A (AKW4507C), For 600A (AKW4508C)



◆ Attached trunk cable (common)



## Revision History

Issue Date	Manual no.	Content of revision
August, 2011	ARCT1F520E	First edition
January, 2012	ARCT1F520E-1	2 <sup>nd</sup> edition Series addition Expansion unit (pulse input) Expansion unit (analog input)
July, 2012	ARCT1F520E-2	3 <sup>rd</sup> edition Series addition Main unit: KW2G-H SD card type
October, 2012	ARCT1F520E-3	4 <sup>th</sup> edition <ul style="list-style-type: none"> <li>• Divide the manual for expansion unit (pulse input) and expansion unit (analog input) and edit this for only main unit and expansion unit (power measurement).</li> <li>[Add functions]</li> <li>• Pulse output width setting</li> <li>• Pulse input status display</li> </ul>
February, 2013	ARCT1F520E-4	5 <sup>th</sup> edition firmware Ver.1.30 [Add functions] <ul style="list-style-type: none"> <li>• Integrated electric power display minimum unit 0.001kWh available</li> <li>• General-purpose output function</li> </ul>
August, 2013	ARCT1F520E-5	8 <sup>th</sup> edition firmware Ver.1.40 [Add functions] <ul style="list-style-type: none"> <li>• SD memory card removing function</li> <li>• Error detection function</li> <li>• Error alarm output function</li> </ul>
November, 2015	ARCT1F520E-6	9 <sup>th</sup> edition firmware Ver.1.50 [Add functions] <ul style="list-style-type: none"> <li>• Hour meter function</li> </ul>

---

Please contact .....

## **Panasonic Industrial Devices SUNX Co., Ltd.**

■ Overseas Sales Division (Head Office): 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

■ Telephone: +81-568-33-7861 ■ Facsimile: +81-568-33-8591

[panasonic.net/id/pidsx/global](http://panasonic.net/id/pidsx/global)

About our sales network, please visit our website.

© Panasonic Industrial Devices SUNX Co., Ltd. 2015

Specifications are subject to change without notice.

ARCT1F520E-6